CHAPTER 6

LIST OF EFFECTIVE TEMPORARY REVISIONS

FOLLOWING IS A COMPLETE LISTING OF ALL ACTIVE TEMPORARY REVISIONS (TR'S). TR'S NOT LISTED SHOULD BE REMOVED. THE ATA NUMBER, CONFIG CODE AND PAGE NUMBER IDENTIFIES THE PAGE PRECEDING THE TR.

TR NUMBER	ATA NUMBER	CONFIG CODE	PAGE NUMBER	TR DATE
NONE				

CHAPTER 5

TIME LIMITS/MAINTENANCE CHECKS

LIST OF EFFECTIVE PAGES

CHAPTER/ SECTION	PAGE	DATE	CONFIG CODE
List of Effective Pages	1/2	Jun 15/96	
Table of Contents	1	May 15/88	
	2	Nov 15/88	
5-00-00	1/2	Mar 15/84	
5-10-00	601/602	Mar 15/84	
5-50-00	601/602	Sep 15/73	
5-50-01	201	Aug 15/81	
5-50-01	202	Aug 15/81	
5-50-01	601	Aug 15/81	
5-50-01	602	Jul 15/83	
5-50-01	603/604	Aug 15/81	
5-50-02	601	May 15/82	
5-50-02	602	Feb 15/79	
5-50-02	603	Feb 15/79	
5-50-02	604	Nov 15/83	
5-50-03	601/602	May 1/72	
5-50-04	601/602	Dec 1/72	
5-50-05	601	Jul 15/84	
5-50-05	602	Aug 15/82	
5-50-05	603/604	Aug 15/82	
5-50-06	601	Aug 15/75	
5-50-06	602	May 15/77	
5-50-07	601/602	Jan 15/73	
5-50-08	601/602	May 15/90	
5-50-09	601/602	Sep 15/73	
5-50-10	601	May 15/88	
5-50-10	602	Jul 15/84	
5-50-10	603/604	Jul 15/84	
5-50-10	605/606	May 15/88	
5-50-11	601/602	Aug 15/81	
5-50-12	601	Aug 15/81	
5-50-12	602	Aug 15/81	
5-50-12	603	Aug 15/81	
5-50-12	604	Aug 15/81	
5-50-12	605/606	Aug 15/81	
5-50-14	601/602	Mar 15/80	
5-50-15	601/602	Mar 15/91	
5-50-20	601	Dec 15/80	
5-50-20	602	Dec 15/80	
5-50-21	601	Mar 15/91	
5-50-21	602	Mar 15/91	
5-50-21	603/604	Mar 15/91	
5-50-42	601	Nov 15/88	
5-50-42	602	Nov 15/88	
5-50-42	603	Nov 15/88	
5-50-42	604	Nov 15/88	
5-51-05	601/602	May 15/82	

CHAPTER 6

DIMENSIONS AND AREAS

LIST OF EFFECTIVE PAGES

CHAPTER/ SECTION	PAGE	DATE	CONFIG CODE
List of Effective Pages	1	Jun 15/96	
	2	Jun 15/96	
Table of Contents	1/2	Nov 15/88	
6-00-00	1	May 15/82	
6-00-00	2	Oct 1/72	
6-10-00	1	Oct 1/72	
6-10-00	2	Nov 15/78	
6-10-00	3	Dec 1/71	
6-10-00	4	Nov 15/78	
6-10-00	5	Feb 15/78	
6-10-00	6	Nov 15/75	
6-10-00	7	Dec 1/72	
6-10-00	8	Nov 15/75	
6-10-00	9	Feb 15/78	
6-10-00	10	Feb 15/78	
6-20-00	1	Oct 1/72	
6-20-00	2	Feb 15/75	
6-20-00	3	Dec 1/71	
6-20-00	4	May 15/82	
6-20-00	5	May 15/82	
6-20-00	6	May 15/82	
6-20-00	7	May 15/82	
6-20-00	8	May 15/82	
6-20-00	9	May 15/82	
6-20-00	10	May 15/82	
6-20-00	11	May 15/82	
6-20-00	12	May 15/82	
6-30-00	1	Oct 1/72	
6-30-00	2	Feb 15/82	
6-30-00	3	Jan 15/72	
6-30-00	4	Dec 1/71	
6-30-00	5	Dec 1/71	
6-30-00	6	Aug 15/82	
6-30-00	7	May 15/77	
6-30-00	8	Aug 15/75	
6-30-00	9	Aug 15/75	
6-30-00	10	May 15/76	
6-30-00	11	Aug 15/75	
6-30-00	12	Aug 15/75	
6-30-00	13	Aug 15/75	
6-30-00	14	Aug 15/75	
6-40-00	1	Oct 1/72	
R 6-40-00	2	Jun 15/96	
6-40-00	3	Jun 15/80	
R 6-40-00	4	Jun 15/96	
6-40-00	5	Aug 15/82	
6-40-00	6	Jun 15/80	
6-40-00	7	Nov 15/83	
6-40-00	8	Jun 15/80	
6-40-00	9	Jun 15/80	
6-40-00	10	Jun 15/80	
6-40-00	11	Jun 15/80	
R 6-40-00	12	Jun 15/96	
6-40-00	13	Dec 15/93	
6-40-00	14	Dec 15/93	
6-40-00	15	Jun 15/80	
6-40-00	16	Sep 15/80	
R 6-40-00	17	Jun 15/96	
6-40-00	18	Jun 15/80	
6-40-00	19	Jun 15/80	
6-40-00	20	Jun 15/80	
6-40-00	21	Jun 15/80	
6-40-00	22	Jun 15/80	
6-40-00	23	Jun 15/80	
6-40-00	24	Jun 15/80	
6-40-00	25	Nov 15/85	
6-40-00	26	Nov 15/85	
6-40-00	27/28	Sep 15/79	
6-40-00	29/30	May 15/76	
6-40-00	31/32	Sep 15/79	
6-40-00	33/34	May 15/76	
6-40-00	35/36	Feb 15/78	
6-40-00	37	Sep 15/79	
6-40-00	38	May 15/76	
6-50-00	1	Jun 15/80	
6-50-00	2	Jun 15/80	
6-50-00	3/4	Aug 15/82	
6-50-00	5/6	Aug 15/82	
6-50-00	7	Aug 15/82	
6-50-00	8	Aug 15/82	

CHAPTER/ SECTION	PAGE	DATE	CONFIG CODE	CHAPTER/ SECTION	PAGE	DATE	CONFIG CODE
6-50-00	9	Aug 15/82					
6-50-00	10	Aug 15/82					
6-50-00	11	Aug 15/82					
6-50-00	12	Aug 15/82					
6-50-00	13	Aug 15/82					
6-50-00	14	Aug 15/82					
6-50-00	15	Aug 15/82					
6-50-00	16	Aug 15/82					
6-50-00	17/18	Aug 15/82					
6-50-00	19/20	Aug 15/82					
6-50-00	21	Aug 15/82					
6-50-00	22	Aug 15/82					
6-50-00	23/24	Aug 15/82					
6-50-00	25/26	Aug 15/82					
6-50-00	27	Aug 15/82					
6-50-00	28	Aug 15/82					
6-50-00	29	Aug 15/82					
6-50-00	30	Aug 15/82					
6-50-00	31	Aug 15/82					
6-50-00	32	Aug 15/82					
6-50-00	33	Aug 15/82					
6-50-00	34	Aug 15/82					
6-50-00	35	Aug 15/82					
6-50-00	36	Aug 15/82					
6-50-00	37/38	Aug 15/82					
6-50-00	39	Aug 15/82					
6-50-00	40	Aug 15/82					
6-50-00	41/42	Aug 15/82					
6-50-00	43/44	Aug 15/82					
6-50-00	45	Aug 15/82					
6-50-00	46	Aug 15/82					
6-50-00	47	Aug 15/82					
6-50-00	48	Aug 15/82					
6-50-00	49	Aug 15/82					
6-50-00	50	Aug 15/82					
6-50-00	51/52	Aug 15/82					
6-50-00	53	Aug 15/82					
6-50-00	54	Nov 15/88					
6-50-00	55	May 15/89					
6-50-00	56	Nov 15/85					
6-50-00	57	Nov 15/88					
6-50-00	58	Nov 15/85					
6-50-00	59/60	Nov 15/85					

CHAPTER 6

DIMENSIONS AND AREAS

TABLE OF CONTENTS

Subject	Chapter Section Subject	Page	Effectivity
DIMENSIONS AND AREAS	6-00-00		
Description and Operation		1	ALL
General			
PRINCIPAL DIMENSIONS	6-10-00		
Description and Operation		1	ALL
General			
STATION DIAGRAMS	6-20-00		
Description and Operation		1	ALL
General			
ZONING DIAGRAMS	6-30-00		
Description and Operation		1	ALL
General			
EXTERIOR ACCESS DOORS AND REMOVABLE PANELS	6-40-00		
Description and Operation		1	ALL
General			
INTERIOR ACCESS DOORS AND REMOVABLE PANELS	6-50-00		
Description and Operation		1	ALL
General			

DIMENSIONS AND AREAS - DESCRIPTION AND OPERATION

1. General

This chapter provides the following aircraft data:

Principal dimensions and areas (Ref. 6-10-00)

Station Diagrams (Ref. 6-20-00)

Zoning system description and diagrams (Ref. 6-30-00)

Exterior access door and removable panel identification description and diagrams (Ref. 6-40-00)

Interior access door and panel identification description and diagrams (Ref. 6-50-00)

The following is a complete list of abbreviations used to designate aircraft stations and areas for the wing and fuselage:

BL - Buttock Line

CL - Center Line

ES - Elevator Station

FS - Fuselage Station

HSBL - Horizontal Stabilizer Buttock Line

HSS - Horizontal Stabilizer Station

R ITES - Inner Trailing Edge Station

IWS - Inner Wing Station

LES - Leading Edge Station

NWL - Nacelle Water Line

OWS - Outer Wing Station

RS - Rudder Station

WBL - Wing Buttock Line

WL - Water Line

WS - Wing Station

The following is a complete list of abbreviations used to designate engine and pylon stations:

EMS - Engine Mount Station

EMWL - Engine Mount Water Line

PPS - Power Plant Station

PS - Pylon Station

PWL - Pylon Water Line

WRP - Wing Reference Plane

PRINCIPAL DIMENSIONS - DESCRIPTION AND OPERATION

1. General

R Principal dimensions and areas of the aircraft are shown as
R follows.





A11-0202-05-013

Aircraft Dimensions - Front and Side Views
Figure 1



M1-A00-06-012

Aircraft Dimensions - Plan View
Figure 2



M1-0102-05-000

R Wing Power Plant Dimensions - Side View
R Figure 3 (Sheet 1)

EFFECTIVITY: ALL

0018



M1-0101-00-01

R
R

Wing Power Plant Dimensions - Side View
Figure 3 (Sheet 2)

EFFECTIVITY: ALL

001B



	A	B	C	D	E	F	G	H
MAXIMUM HEIGHT	27 FT 4 IN. 8.32 M	16 FT 0 IN. 4.88 M	9 FT 8 IN. 2.95 M	8 FT 10 IN. 2.69 M	15 FT 9 IN. 4.8 M	3 FT 8 IN. 1.12 M	9 FT 6 IN. 2.9 M	15 FT 7 IN. 4.75 M
MINIMUM HEIGHT	26 FT 4 IN. 8.02 M	15 FT 0 IN. 4.57 M	8 FT 11 IN. 2.72 M	8 FT 2 IN. 2.5 M	15 FT 1 IN. 4.6 M	2 FT 11 IN. 0.89 M	8 FT 8 IN. 2.64 M	15 FT 0 IN. 4.57 M

	I	J	K	L	M	N	O
MAXIMUM HEIGHT	9 FT 7 IN. 2.92 M	10 FT 0 IN. 3.05 M	15 FT 8 IN. 4.78 M	16 FT 5 IN. 5.0 M	20 FT 6 IN. 6.28 M	37 FT 2 IN. 11.34 M	56 FT 0 IN. 17.7 M
MINIMUM HEIGHT	8 FT 2 IN. 2.5 M	8 FT 7 IN. 26.2 M	14 FT 8 IN. 4.47 M	15 FT 5 IN. 4.7 M	19 FT 8 IN. 6.0 M	36 FT 2 IN. 11.03 M	55 FT 0 IN. 16.76 M

NOTE

CHART PROVIDES MAXIMUM AND MINIMUM HEIGHTS WHICH MAY BE EXPERIENCED THROUGH NORMAL CHANGES IN AIRCRAFT LOADING AND CG.

EXAMPLE: LOCATION A
MAXIMUM HEIGHT; AIRCRAFT AT OEW + 40,000 POUNDS LOADED IN AFT CG CONDITION
MINIMUM HEIGHT; AIRCRAFT AT MAXIMUM TAXI WEIGHT LOADED IN FORWARD CG CONDITION

M1-0005-06-015

R
R

General Ground Clearance
Figure 4



BOTTOM VIEW LOOKING UP

NOTE

1. FLUSH TYPE ANTENNAS NOT SHOWN
2. ALL CLEARANCES ARE BASED ON A MAXIMUM RAMP WEIGHT (AIRWAY) OF 432,000 LB (195,918 KG), CG AT 25.5% MAC AND 50 x 20 MLG TIRES

M1-0101-06-013

R
R

Antenna Ground Clearance
Figure 5

EFFECTIVITY: ALL

0508


LEFT SIDE ONLY
LEFT AND RIGHT SIDES
PASSENGER DOOR (L1)
PASSENGER DOOR (L2 & R2)
PASSENGER DOOR (L3 & R3)
EMERGENCY DOOR (L4 & R4)
TYPE A FS 306.5 42 X 76 IN. 1.066 X 1.930 M
TYPE A FS 873.0 42 X 76 IN. 1.066 X 1.930 M
TYPE A FS 1513.0 42 X 76 IN. 1.066 X 1.930 M
TYPE 1 FS 1778.0 24 X 60 IN. 0.609 X 1.524 M
FS 83
GROUND LINE WL19
TYPE A FS 351.0 42 X 76 IN. 1.066 X 1.930 M
FS 666.0 70 X 68 IN. 1.778 X 1.727 M
FS 810.6 32 X 61.5 IN. 0.812 X 1.562 M
FS 1585.0 70 X 68 IN. 1.778 X 1.727 M
FS 1701.0 44 X 48 IN. 1.117 X 1.219M
PASSENGER DOOR (R1)
FORWARD CARGO COMPARTMENT DOOR (C-1)
GALLEY DOOR (G-1)
CENTER CARGO COMPARTMENT DOOR (C-2)
AFT CARGO COMPARTMENT DOOR (C-3)
RIGHT SIDE ONLY

M1-0034-06-019

R R Door Size and Location Data
Figure 6

EFFECTIVITY: ALL

0018



Landing Gear Footprint Dimensions
Figure 7



NOTE

1. WASTE WATER DRAIN MAST (MID BODY) - LOCATED AT FS 846 AND LBL 11.94. REFERENCE 38-32-00, 30-71-00 AND 30-71-10
2. KEELSON DRAIN MAST - LOCATED AT FS 1358 AND RBL 38. REFERENCE 51-10-00 AND 51-10-01
3. AFTERBODY DRAIN MAST - LOCATED AT FS 1685 AND LBL 35.28 (DRAINS AREA AFT OF AFT PRESSURE BULKHEAD). REFERENCE 51-10-00 AND 51-10-03
4. WASTE WATER DRAIN MAST (AFT) - LOCATED AT FS 1792 AND RBL 30.3. REFERENCE 38-32-00, 30-71-00 AND 30-71-10
5. APU COMPARTMENT DRAIN MAST - LOCATED AT FS 1854 AND LBL 39 (THIS MAST HAS TWO DRAINS - ONE FOR APU COMPARTMENT AND OTHER FOR NO. 2 ENGINE FIRE LINE AFT SHROUD) REFERENCE 51-10-00 AND 51-10-04
6. FOR COORDINATION PURPOSES, REFER TO 51-10-00, FIGURE 1

M1-0100-06-223

R R Fuselage Drain Mast Locations
Figure 8

R R EFFECTIVITY: ALL

001B

STATION DIAGRAMS - DESCRIPTION AND OPERATION

1. General

R Aircraft stations and major structural components are shown as
R follows.



CODE

FS - FUSELAGE STATION
WL - WATER LINE

NOTE

1 THE TWO FORWARD WINDOWS SHOWN ARE ON LEFT SIDE ONLY

2 BEGINNING AT FRONT OF CABIN, ALL WINDOWS (LEFT AND RIGHT) WILL BE NUMBERED CONSECUTIVELY AS 1L, 1R, 2L, 2R, ETC

R
R

Fuselage Station Diagram
Figure 1 (Sheet 1)

EFFECTIVITY: ALL

0018



Fuselage Station Diagram
Figure 1 (Sheet 2)



R
R

Wing Station Diagram
Figure 2 (Sheet 1)

EFFECTIVITY: ALL

001B



M1-000-06-408

R
R

Wing Station Diagram
Figure 2 (Sheet 2)

EFFECTIVITY: ALL



HH 4338
152E001
AH1-0102-06-027

Horizontal Stabilizer and Elevator Station Diagram
Figure 3



MI-0101-06-028

Afterbody Station Diagram
Figure 4

R
R
0018 EFFECTIVITY: ALL



Vertical Stabilizer and Rudder Station Diagram
Figure 5



CODE

EMS	DENOTES	ENGINE MOUNT STA
PPWL		POWER PLANT WATER LINE
PPS		POWER PLANT STATION
PWL		PYLON WATER LINE
PS		PYLON STATION
WBL		WING BUTTOCK LINE
BL		BUTTOCK LINE
WRP		WING REFERENCE PLANE
EMWL	DENOTES	ENGINE MOUNT WATER LINE

A11-0101-06-029

No. 1 and No. 3 Power Plant and Pylon Station Diagram
Figure 6



CODE		
EMS	DENOTES	ENGINE MOUNT STA
PPWL		POWER PLANT WATER LINE
PPS		POWER PLANT STATION
PWL		PYLON WATER LINE
PS		PYLON STATION
WBL		WING BUTTOCK LINE
BL		BUTTOCK LINE
WRP		WING REFERENCE PLANE
EMWL	DENOTES	ENGINE MOUNT WATER LINE

M3-0000-06-367

Powerplant and Pylon Station Diagram
Figure 6

CODE

WBL - WING BUTTOCK LINE
LE - LEADING EDGE
PWL - PYLON WATERLINE
PS - PYLON STATION
PPS - POWER PLANT STATION
PP - POWER PLANT



M1-A00-00-041

No. 1 and No. 3 Pylon Station Diagram
Figure 7





CODE
FS - FUSELAGE STATION
WL - WATERLINE

AM-A00-06-042

Center Engine Support Structure Station Diagram
Figure 8

ZONING DIAGRAMS - DESCRIPTION AND OPERATION

1. General

The L-1011 is divided into numbered zones to provide a method for designating and locating components and structural parts and areas. The zoning system aids in planning maintenance and preparing job instructions.

The zones are identified by a three-digit number. Each digit designates a zone category: major, sub-major, or zone.

A major zone is designated by the first digit of the three-digit number. Two zeros after a digit (100, 200, etc.) imply that it is a major zone designation only. The aircraft is divided into eight zones (Ref. Fig. 1).

Sub-major zones which are sub-divisions of major zones, are designated by the second digit of the three-digit number. One zero after two digits (130, 160, etc.) implies that it is a major and sub-major zone designation only.

Zones which are subdivisions of sub-major zones, are designated by the third digit of the three-digit number (111, 232, etc).

In numbering the major zones and their subdivisions, the following guidelines have been followed:

A. Wherever possible, odd numbers indicate left side zones and even numbers indicate right side zones relative to the fuselage or power plant center lines.

B. The sequence of zone numbers run, wherever possible, in ascending order from front to back in the fuselage from front to back and inboard to outboard in the wing and horizontal tail and from root to tip in the vertical tail.

C. Individual zone numbers are assigned to major structural components cabin and cargo service doors, landing gear doors, and primary and secondary flight control surfaces.

D. Wherever possible, the zones are defined by physical boundaries such as spars, major bulkheads, and partitions.

R E. Aircraft major zones are shown as follows.



MAJOR ZONES

MAJOR ZONE 100 - LOWER PART OF FUSELAGE
MAJOR ZONE 200 - UPPER PART OF FUSELAGE
MAJOR ZONE 300 - AFTERBODY AND EMPENNAGE
MAJOR ZONE 400 - POWER PLANTS AND PYLONS
MAJOR ZONE 500 - WING, LEFT
MAJOR ZONE 600 - WING, RIGHT
MAJOR ZONE 700 - LANDING GEAR AND LG DOORS
MAJOR ZONE 800 - DOORS
MAJOR ZONE 900 - RESERVED FOR UNCOMMON DIFFERENCES BETWEEN AIRPLANE TYPES NOT COVERED BY ABOVE MAJOR ZONES

M1-0001-06-007

R
R

Major Zones
Figure 1

EFFECTIVITY: ALL

0018



Major Zone 100 - Lower Half of Fuselage
Figure 2 (Sheet 1)

MAJOR ZONE 100 - LOWER HALF OF FUSELAGE

SUBMAJOR ZONE 110 - FS 83 TO FS 449
SUBMAJOR ZONE 120 - FS 449 TO FS 703
SUBMAJOR ZONE 130 - FS 703 TO FS 983
SUBMAJOR ZONE 140 - FS 983 TO FS 1363
SUBMAJOR ZONE 150 - FS 1363 TO FS 1625
SUBMAJOR ZONE 160 - FS 1625 TO FS 1860
SUBMAJOR ZONE 170 - NOT ASSIGNED
SUBMAJOR ZONE 180 - NOT ASSIGNED
SUBMAJOR ZONE 190 - FAIRINGS - FS 73[illegible].5 TO FS 1665

110 FS 83 TO FS 449

111 RADOME
112 ELECTRONICS SERVICE CENTER, FWD, AREA I
113 ELECTRONICS SERVICE CENTER, FWD, AREA II AND WASTE SYS COMPT, FWD
114 NLG WHEEL WELL COMPT
115 HEAT EXCHANGER COMPT, LEFT
116 HEAT EXCHANGER COMPT, RIGHT
117 ENVIRONMENTAL CONTROL SYS COMPT, LEFT
118 ENVIRONMENTAL CONTROL SYS COMPT, RIGHT
119 AREA ABOVE NLG COMPT

120 FS 449 TO FS 703

121 CARGO COMPT, FWD
122 SIDE COMPT, RIGHT
123 SIDE COMPT, LEFT
124 AREA BELOW FWD CARGO COMPT
125 AREA ABOVE FWD CARGO COMPT

130 FS 703 TO FS 983

131 GALLEY COMPT
132 SIDE COMPT, RIGHT
133 SIDE COMPT, LEFT
134 GALLEY LIFT
135 AREA ABOVE GALLEY
136 AREA BELOW GALLEY COMPT
137 MID ELECTRICAL SERVICE CENTER AND AREA BELOW
138 SIDE COMPT, RIGHT
139 SIDE COMPT, LEFT

140 FS 983 TO FS 1363

141 WING CENTER SECTION BOX
142 AREA BELOW CENTER OF WING CENTER SECTION BOX
143 AREA BELOW AND LEFT OF WING CENTER SECTION BOX
144 AREA BELOW AND RIGHT OF WING CENTER SECTION BOX
145 AREA ABOVE WING CENTER SECTION BOX
146 AREA ABOVE HYDRAULIC SERVICE CENTER COMPT
147 HYDRAULIC SERVICE CENTER COMPT AND AREA BELOW
148 MLG WHEEL WELL COMPT, RIGHT
149 MLG WHEEL WELL COMPT, LEFT

150 FS 1363 TO FS 1625

151 CARGO COMPT, CENTER
152 SIDE COMPT, RIGHT
153 SIDE COMPT, LEFT
154 AREA BELOW CENTER CARGO COMPT
155 AREA ABOVE CENTER CARGO COMPT

160 FS 1625 TO FS 1860

161 CARGO COMPT, AFT
162 SIDE COMPT, RIGHT
163 SIDE COMPT, LEFT
164 ELECTRONICS EQUIPMENT AREA, AFT
165 AREA ABOVE AFT CARGO COMPT
166 AREA BELOW AFT CARGO COMPT
167 WASTE SYSTEM COMPT, AFT
168 AFT FUSELAGE FAIRING/AREA, RIGHT
169 AFT FUSELAGE FAIRING/AREA, LEFT

HH 4481
M1-0101-06-018



MAJOR ZONE 100 - LOWER HALF OF FUSELAGE
SUBMAJOR ZONE 190 - FS 737.5 TO FS 1665

191	FAIRING, FORWARD, LEFT	195	FAIRING, AFT, LEFT
192	FAIRING, FORWARD, RIGHT	196	FAIRING, AFT, RIGHT
193	FAIRING, LOWER, LEFT	197	FILLETS, LEFT
194	FAIRING, LOWER, RIGHT	198	FILLETS, RIGHT

IIH 4654
MI-A00-06-035

Major Zone 100 - Lower Half of Fuselage
Figure 2 (Sheet 2)



MAJOR ZONE 200 - UPPER HALF OF FUSELAGE

SUBMAJOR ZONE 210 - FS 128 TO FS 251
SUBMAJOR ZONE 220 - FS 251 TO FS 378.5
SUBMAJOR ZONE 230 - FS 378.5 TO FS 649
SUBMAJOR ZONE 240 - FS 649 TO FS 901
SUBMAJOR ZONE 250 - FS 901 TO FS 1223
SUBMAJOR ZONE 260 - FS 1223 TO FS 1535
SUBMAJOR ZONE 270 - FS 1535 TO FS 1792
SUBMAJOR ZONE 280 - FS 1792 TO FS 1860

210 FS 128 TO FS 251

211 FLIGHT STATION, LEFT
212 FLIGHT STATION, RIGHT
213 AREA ABOVE CEILING, LEFT
214 AREA ABOVE CEILING, RIGHT
215 FLIGHT ENGINEERS STATION
216 AREA ABOVE CEILING, FLT ENGR STA

220 FS 250 TO FS 378.5

221 LAVATORY, FWD, LEFT
222 LAVATORY, FWD, RIGHT
223 PASSENGER COMPT, LEFT
224 PASSENGER COMPT, RIGHT
225 AREA ABOVE CEILING, LEFT
226 AREA ABOVE CEILING, RIGHT

230 FS 378.5 TO FS 649

231 PASSENGER COMPT, LEFT
232 PASSENGER COMPT, RIGHT
233 AREA ABOVE CEILING, LEFT
234 AREA ABOVE CEILING, RIGHT

240 FS 649 TO FS 901

241 PASSENGER COMPT, LEFT
242 PASSENGER COMPT, RIGHT
243 AREA ABOVE CEILING, LEFT
244 AREA ABOVE CEILING, RIGHT

250 FS 901 TO FS 1223

251 PASSENGER COMPT, LEFT
252 PASSENGER COMPT, RIGHT
253 AREA ABOVE CEILING, LEFT
254 AREA ABOVE CEILING, RIGHT

260 FS 1223 TO FS 1535

261 PASSENGER COMPT, LEFT
262 PASSENGER COMPT, RIGHT
263 AREA ABOVE CEILING, LEFT
264 AREA ABOVE CEILING, RIGHT

270 FS 1535 TO FS 1792

271 PASSENGER COMPT, LEFT
272 PASSENGER COMPT, RIGHT
273 AREA ABOVE CEILING, LEFT
274 AREA ABOVE CEILING, RIGHT

280 FS 1792 TO FS 1860

281 LAVATORY, LEFT, & AREA ABOVE CEILING
282 LAVATORY, LEFT INTERMEDIATE & AREA ABOVE CEILING
283 LAVATORY, CENTER, & AREA ABOVE CEILING
284 LAVATORY, RIGHT INTERMEDIATE, & AREA ABOVE CEILING
285 LAVATORY, RIGHT, & AREA ABOVE CEILING

MI-A00-06-023

Major Zone 200 - Upper Half of Fuselage
Figure 3



MAJOR ZONE 300 - AFTERBODY AND EMPENNAGE

SUBMAJOR ZONE 310 - AFT BODY AND CENTER ENGINE AIR INLET
SUBMAJOR ZONE 320 - VERTICAL STABILIZER
SUBMAJOR ZONE 330 - HORIZONTAL STABILIZER, LEFT
SUBMAJOR ZONE 340 - HORIZONTAL STABILIZER, RIGHT
SUBMAJOR ZONE 350 - HORIZONTAL STABILIZER, CENTER SECTION

310 AFTERBODY AND CENTER ENGINE AIR INLET

311 CENTER ENGINE AIR INLET FRONT
312 CENTER ENGINE "S" DUCT
313 AFTERBODY DORSAL SADDLE SECTION
314 AFTERBODY UPPER SECTION, AFT
315 DIVERTER
316 PRESSURE BULKHEAD AREA
317 AFTERBODY MID/LOWER SECTION
318 AFTERBODY AFT/LOWER SECTION
319 APU COMPARTMENT

320 VERTICAL STABILIZER AND RUDDER

321 VERTICAL STABILIZER LEADING EDGE
322 VERTICAL STABILIZER, FRONT SPAR TO REAR SPAR
323 VERTICAL STABILIZER TIP
324 VERTICAL STABILIZER TRAILING EDGE
325 RUDDER

330 HORIZONTAL STABILIZER, LEFT

331 HORIZONTAL STABILIZER LEADING EDGE
332 HORIZONTAL STABILIZER, AUXILIARY SPAR TO FRONT SPAR
333 HORIZONTAL STABILIZER, FRONT SPAR TO REAR SPAR
334 HORIZONTAL STABILIZER TRAILING EDGE
335 ELEVATOR
336 HORIZONTAL STABILIZER TIP
337 AIRGATE FAIRING

340 HORIZONTAL STABILIZER, RIGHT

341 HORIZONTAL STABILIZER EDGE
342 HORIZONTAL STABILIZER, AUXILIARY SPAR TO FRONT SPAR
343 HORIZONTAL STABILIZER, FRONT SPAR TO REAR SPAR
344 HORIZONTAL STABILIZER TRAILING EDGE
345 ELEVATOR
346 HORIZONTAL STABILIZER TIP
347 AIRGATE FAIRING

350 HORIZONTAL STABILIZER CENTER SECTION

M1-0002-06-032

R
R

Major Zone 300 - Afterbody and Empennage
Figure 4



SUBMAJOR ZONES 450, 460



SUBMAJOR ZONES 410, 420

MAJOR ZONE 400 - POWER PLANTS AND PYLONS

SUBMAJOR ZONE 410 - ENGINE NO. 1, LEFT
SUBMAJOR ZONE 420 - ENGINE NO. 3, RIGHT
SUBMAJOR ZONE 430 - ENGINE NO. 2, CENTER
SUBMAJOR ZONE 440 - NOT USED
SUBMAJOR ZONE 450 - ENGINE PYLON NO. 1, LEFT
SUBMAJOR ZONE 460 - ENGINE PYLON NO. 3, RIGHT
SUBMAJOR ZONE 470 - ENGINE PYLON NO. 2, CENTER

410 ENGINE NO. 1, LEFT

411 NOSE COWL
412 ENGINE
413 MAIN COWL DOOR, LEFT
414 MAIN COWL DOOR, RIGHT
415 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
416 REAR COWL PANELS, RIGHT
417 REAR COWL PANELS, LEFT
418 THRUST SPOILER/NOZZLE AND SUBASSEMBLIES

420 ENGINE NO. 3, RIGHT

421 NOSE COWL
422 ENGINE
423 MAIN COWL DOOR, LEFT
424 MAIN COWL DOOR, RIGHT
425 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
426 REAR COWL PANELS, RIGHT
427 REAR COWL PANELS, LEFT
428 THRUST SPOILER/NOZZLE AND SUBASSEMBLIES

450 ENGINE PYLON NO. 1, LEFT

451 NOSE FAIRING
452 SUPPORT STRUCTURE/TORQUE BOX
453 DRAG STRUT/REAR FAIRING

460 ENGINE PYLON NO. 3, RIGHT

461 NOSE FAIRING
462 SUPPORT STRUCTURE/TORQUE BOX
463 DRAG STRUT/REAR FAIRING

M1-[illegible]-[illegible]

R
R

Major Zone 400 - Power Plants and Pylon
Figure 5 (Sheet 1)



SUBMAJOR ZONES 450, 460



SUBMAJOR ZONES 410, 420

MAJOR ZONE 400 - POWER PLANTS AND PYLONS

SUBMAJOR ZONE 410 - ENGINE NO. 1, LEFT
SUBMAJOR ZONE 420 - ENGINE NO. 3, RIGHT
SUBMAJOR ZONE 430 - ENGINE NO. 2, CENTER
SUBMAJOR ZONE 440 - NOT USED
SUBMAJOR ZONE 450 - ENGINE PYLON NO. 1, LEFT
SUBMAJOR ZONE 460 - ENGINE PYLON NO. 3, RIGHT
SUBMAJOR ZONE 470 - ENGINE PYLON NO. 2, CENTER

410 ENGINE NO. 1, LEFT

411 NOSE COWL
412 ENGINE
413 MAIN COWL DOOR, LEFT
414 MAIN COWL DOOR, RIGHT
415 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
416 REAR COWL PANELS, RIGHT
417 REAR COWL PANELS, LEFT
418 HOT NOZZLE FAIRING

420 ENGINE NO. 3, RIGHT

421 NOSE COWL
422 ENGINE
423 MAIN COWL DOOR, LEFT
424 MAIN COWL DOOR, RIGHT
425 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
426 REAR COWL PANELS, RIGHT
427 REAR COWL PANELS, LEFT
428 HOT NOZZLE FAIRING

450 ENGINE PYLON NO. 1, LEFT

451 NOSE FAIRING
452 SUPPORT STRUCTURE/TORQUE BOX
453 DRAG STRUT/REAR FAIRING

460 ENGINE PYLON NO. 3, RIGHT

461 NOSE FAIRING
462 SUPPORT STRUCTURE/TORQUE BOX
463 DRAG STRUT/REAR FAIRING

R Major Zone 400 - Power Plants and Pylon
R Figure 5 (Sheet 1)

EFFECTIVITY: 11- OR 15-DEGREE AFTERBODY



430 ENGINE NO. 2, CENTER

- 431 S-DUCT ADAPTER
- 432 ENGINE
- 433 MAIN COWL DOORS AND PANEL, LEFT
- 434 MAIN COWL DOORS AND PANEL, RIGHT
- 435 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
- 436 REAR COWL PANELS, RIGHT
- 437 REAR COWL PANELS, LEFT
- 438 THRUST SPOILER/NOZZLE AND SUBASSEMBLIES
- 439 FIREWALL, CANTED BULKHEAD, AFT FACE

470 CENTER ENGINE SUPPORT STRUCTURE

- 471 SUPPORT STRUCTURE
- 472 REAR FAIRING

M1-[illegible]-00-[illegible]

R
33

Major Zone 400 - Power Plants and Pylon
Figure 5 (Sheet 2)

EFFECTIVITY: N-14 AFTERBODY ONLY

0018



11° ENGINE AFTERBODY

430 ENGINE NO. 2, CENTER
- 431 S-DUCT ADAPTER
- 432 ENGINE
- 433 MAIN COWL DOORS AND PANEL, LEFT
- 434 MAIN COWL DOORS AND PANEL, RIGHT
- 435 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
- 436 REAR COWL PANELS, RIGHT
- 437 REAR COWL PANELS, LEFT
- 438 HOT NOZZLE FAIRING
- 439 FIREWALL, CANTED BULKHEAD, AFT FACE

470 CENTER ENGINE SUPPORT STRUCTURE
- 471 SUPPORT STRUCTURE
- 472 REAR FAIRING

M1-0101-06-200

R
R

Major Zone 400 - Power Plants and Pylon
Figure 5 (Sheet 2)

EFFECTIVITY: 11-DEGREE AFTERBODY



15° ENGINE AFTERBODY

430 ENGINE NO. 2, CENTER
- 431 S-DUCT ADAPTER
- 432 ENGINE
- 433 MAIN COWL DOORS AND PANEL, LEFT
- 434 MAIN COWL DOORS AND PANEL, RIGHT
- 435 TRANSLATING COWL, THRUST REVERSER ASSEMBLY
- 436 REAR COWL PANELS, RIGHT
- 437 REAR COWL PANELS, LEFT
- 438 HOT NOZZLE FAIRING
- 439 FIREWALL, CANTED BULKHEAD, AFT FACE

470 CENTER ENGINE SUPPORT STRUCTURE
- 471 SUPPORT STRUCTURE
- 472 REAR FAIRING

M1-0100-06-199



LEFT WING - LOOKING DOWN AND FWD

MAJOR ZONE 500 - WING, LEFT

SUBMAJOR ZONE 510 - LEADING EDGE TO FRONT SPAR, WBL 116.48 TO WBL 419.93
SUBMAJOR ZONE 520 - LEADING EDGE TO FRONT SPAR, WBL 419.93 TO LES 1027.17
SUBMAJOR ZONE 530 - FRONT SPAR TO REAR SPAR, WBL 116.48 TO AND INCLUDING WING TIP ASSEMBLY
SUBMAJOR ZONE 540 - REAR SPAR TO TRAILING EDGE, WBL 116.48 TO WBL 394.4
SUBMAJOR ZONE 550 - REAR SPAR TO TRAILING EDGE, WBL 394.4 TO WBL 486.5
SUBMAJOR ZONE 560 - REAR SPAR TO TRAILING EDGE, WBL 486.5 TO WBL 743.0
SUBMAJOR ZONE 570 - REAR SPAR TO TRAILING EDGE, WBL 743.0 TO WBL 923.3

510 LEADING EDGE TO FRONT SPAR, WBL 116.48 TO WBL 419.93
- 511 FIXED STRUCTURE
- 512 SLAT NO. 1
- 513 SLAT NO. 2
- 514 SLAT NO. 3

520 LEADING EDGE TO FRONT SPAR, WBL 419.93 TO LES 1027.17
- 521 FIXED STRUCTURE
- 522 SLAT NO. 4
- 523 SLAT NO. 5
- 524 SLAT NO. 6
- 525 SLAT NO. 7

530 FRONT SPAR TO REAR SPAR, WBL 116.48 TO AND INCLUDING WING TIP ASSEMBLY
- 531 INBOARD MAIN TANK
- 532 OUTBOARD MAIN TANK, SECTION 1
- 533 OUTBOARD MAIN TANK, SECTION 2
- 534 VENT SURGE TANK
- 535 WING TIP ASSEMBLY

540 REAR SPAR TO TRAILING EDGE, WBL 116.48 TO WBL 394.4
- 541 FIXED STRUCTURE
- 542 MAIN LANDING GEAR COMPT
- 543 SPOILER NO. 1
- 544 SPOILER NO. 2
- 545 FLAP AND VANE NO. 1
- 546 FLAP AND VANE NO. 2

550 REAR SPAR TO TRAILING EDGE, WBL 394.4 TO WBL 486.5
- 551 FIXED STRUCTURE
- 552 INBOARD AILERON

560 REAR SPAR TO TRAILING EDGE, WBL 486.5 TO WBL 743.0
- 561 FIXED STRUCTURE
- 562 SPOILER NO. 3
- 563 SPOILER NO. 4
- 564 SPOILER NO. 5
- 565 SPOILER NO. 6
- 566 FLAP AND VANE NO. 3
- 567 FLAP AND VANE NO. 4

570 REAR SPAR TO TRAILING EDGE, WBL 743.0 TO WBL 923.3
- 571 FIXED STRUCTURE
- 572 OUTBOARD AILERON

MAJOR ZONE 600 - WING, RIGHT

SUBMAJOR ZONES AND ZONES ARE IDENTICAL TO THEIR SYMMETRICAL COUNTERPARTS OF MAJOR ZONE 500 - WING, LEFT. FOR SPECIFIC ZONE NUMBERS THE FIRST DIGIT "6" IS SUBSTITUTED FOR A "5"

HH 4702 M1-A00-06-036

Major Zones 500 and 600 - Wing, Left and Right
Figure 6



MAJOR ZONE 700 - LANDING GEAR AND DOORS

SUBMAJOR ZONE 710 - NOSE LANDING GEAR AND DOORS
SUBMAJOR ZONE 720 - NOT ASSIGNED
SUBMAJOR ZONE 730 - LEFT MAIN LANDING GEAR AND DOORS
SUBMAJOR ZONE 740 - RIGHT MAIN LANDING GEAR AND DOORS

710 NOSE LANDING GEAR AND DOORS

711 NOSE LANDING GEAR
712 NOSE LANDING GEAR RIGHT FORWARD DOOR
713 NOSE LANDING GEAR LEFT FORWARD DOOR
714 NOSE LANDING GEAR RIGHT AFT DOOR
715 NOSE LANDING GEAR LEFT AFT DOOR

730 MAIN LANDING GEAR AND DOORS, LEFT

731 MAIN LANDING GEAR
732 MAIN LANDING GEAR INBOARD DOOR
733 MAIN LANDING GEAR OUTBOARD DOOR
734 MAIN LANDING GEAR STRUT DOOR

740 MAIN LANDING GEAR AND DOORS, RIGHT

741 MAIN LANDING GEAR
742 MAIN LANDING GEAR INBOARD DOOR
743 MAIN LANDING GEAR OUTBOARD DOOR
744 MAIN LANDING GEAR STRUT DOOR



HH 4701
M1-A00-06-037

Major Zone 700 - Landing Gear and Doors
Figure 7



MAJOR ZONE 800 - DOORS (PASSENGER-CARGO-GALLEY)

SUBMAJOR ZONE 810 - LOWER HALF OF FUSELAGE, LEFT
SUBMAJOR ZONE 820 - LOWER HALF OF FUSELAGE, RIGHT
SUBMAJOR ZONE 830 - UPPER HALF OF FUSELAGE, LEFT
SUBMAJOR ZONE 840 - UPPER HALF OF FUSELAGE, RIGHT

810 LOWER HALF OF FUSELAGE, LEFT

NO DOORS IN THIS ZONE

820 LOWER HALF OF FUSELAGE, RIGHT

821 CARGO COMPT DOOR, FWD (C-1)
822 GALLEY COMPT DOOR (G-1)
823 CARGO COMPT DOOR, CENTER (C-2)
824 CARGO COMPT DOOR, AFT (C-3)

830 UPPER HALF OF FUSELAGE, LEFT

831 FLIGHT COMPT HATCH
832 PASSENGER COMPT DOOR, FWD (P-1)(L-1)
833 PASSENGER COMPT DOOR, CENTER (P-3L)(L-2)
834 PASSENGER COMPT DOOR, AFT (P-4L)(L-3)
835 EMERGENCY DOOR (P-5L)(L-4)

840 UPPER HALF OF FUSELAGE, RIGHT

842 PASSENGER COMPT DOOR, FWD (P-2)(R-1)
843 PASSENGER COMPT DOOR, CENTER (P-3R)(R-2)
844 PASSENGER COMPT DOOR, AFT (P-4R)(R-3)
845 EMERGENCY DOOR (P-5R)(R-4)

HH 4479
M1-1602-06-038

Major Zone 800 - Doors
Figure 8

R R EXTERIOR ACCESS DOORS AND REMOVABLE PANELS
R DESCRIPTION AND OPERATION

1. General

R R R R R External maintenance and service access doors, and removable panels are identified by a three-digit zone number which designates the smallest zone division in which the door is located. A two letter suffix to the zone number identifies and locates the door or panel within the zone (Ref. Fig. 1).

The first letter of the suffix is the primary letter which identifies the door or panel in a logical sequence, beginning with A, within each zone, inboard to outboard or front to rear and from root to tip in the vertical tail. The second letter, or locater, locates the door or panel in relation to the aircraft as follows:

T - Top

B - Bottom

L - Left Side

R - Right Side

Z - Interior

R R R Location, identification and function of exterior access doors and removable panels and their identification numbers are shown as follows.



NOTE
LEFT SIDE SHOWN

ACCESS IDENTIFICATION NUMBER	ACCESS TO
111A	WEATHER RADAR ANTENNA
112AB	AUTOMATIC FLIGHT CONTROL SYSTEM COMPONENTS, AND FORWARD WASTE SYSTEM
113AB	FORWARD WASTE SYSTEM SERVICE PANEL
115AL	LEFT HEAT EXCHANGER COMPARTMENT
115AL-1	ACTUATOR
117AL	LEFT ENVIRONMENTAL CONTROL SYSTEM COMPARTMENT
117BL	NLG TRUNNION PIN, LEFT SIDE
117CL	LEFT NOSE JACK/TIE DOWN FITTING
137AZ	MID ELECTRICAL SERVICE CENTER

HH 0827
M1-0102-00-001

Exterior Access Doors and Panels, Zone 100
Lower Half if Fuselage, Left Side
Figure 1

R
R
001B

EFFECTIVITY: ALL



NOTE
LEFT SIDE SHOWN

ACCESS IDENTIFICATION NUMBER	ACCESS TO
169A	LOWER AFTERBODY STRUCTURE

M1-0101-06-096

R Exterior Access Doors and Panels, Zone 100
R Lower Half of Fuselage, Aft Left Side
R Figure 2

EFFECTIVITY: ALL



ACCESS IDENTIFICATION NUMBER	ACCESS TO
112AB	FORWARD ELECTRONICS SERVICE CENTER
113AB	FORWARD WASTE SYSTEM SERVICE PANEL
115AL	LEFT HEAT EXCHANGER COMPARTMENT
115AL-1	ACTUATOR
116AR	RIGHT HEAT EXCHANGER COMPARTMENT, LOWER AREA
116AR-1	ACTUATOR
116BR	RIGHT HEAT EXCHANGER COMPARTMENT, UPPER AREA
116BR-1	ACTUATOR
117AL	ENVIRONMENTAL CONTROL SYSTEM COMPARTMENT, LEFT SIDE
117BL	NLG TRUNNION PIN, LEFT SIDE
117CL	LEFT NOSE JACK/TIE DOWN FITTING
118AB	GROUND AIR CONDITIONING RECEPTACLE FWD
118BB	GROUN AIR CONDITIONING RECEPTACLE AFT
118CR	ENVIRONMENTAL CONTROL SYSTEM COMPARTMENT, RIGHT SIDE
118DR	NLG TRUNNION PIN, RIGHT SIDE
118ER	RIGHT NOSE JACK/TIE DOWN FITTING
124AB	EXTERNAL POWER RECEPTACLE

HH 5691
M1-0102-06-002

Exterior Access Doors and Panels, Zoom 100,
Lower Half of Fuselage, Bottom
Figure 3



ACCESS IDENTIFICATION NUMBER	ACCESS TO
142AB	GROUND AIR START RECEPTACLE, RIGHT
142BB	GROUND AIR START RECEPTACLE, CENTER
142CB	GROUND AIR START RECEPTACLE, LEFT
142DB	PNEUMATIC DUCTING AND ECS ISOLATION VALVE
142EB	PNEUMATIC DUCTING AND KEELSON CENTER
142FB	APU EXTERNAL CONTROL
142GB	PNEUMATIC DUCTING, KEELSON CENTER COMPARTMENT
142HB	RAM AIR TURBINE
147AB	HYDRAULIC SERVICE CENTER FORWARD AREA
147BB	HYDRAULIC SERVICE CENTER AFT AREA

M1-0104-06-003

Exterior Access Doors and Panels, Zone 100,
Lower Half of Fuselage, Wing Bay Section
Figure 4



NOTE
BOTTOM VIEW LOOKING UP

ACCESS IDENTIFYING NUMBER	ACCESS TO:
147BB 167AB	HYDRAULIC SERVICE CENTER, AFT AREA AFT WASTE SYSTEM SERVICE PANEL

bm 5694
M1-A00-06-004

Exterior Access Doors and Panels, Zone 100
Lower Half of Fuselage, Aft Section
Figure 5



NOTE

RIGHT SIDE SHOWN

ACCESS IDENTIFYING NUMBER	ACCESS TO
116 AR	RIGHT HEAT EXCHANGER COMPARTMENT, LOWER AREA
116 AR-1	ACTUATOR
116 BR	RIGHT HEAT EXCHANGER COMPARTMENT, UPPER AREA
116 BR-1	ACTUATOR
118 CR	RIGHT ENVIRONMENTAL CONTROL SYSTEM COMPARTMENT
118 DR	NLG TRUNNION PIN, RIGHT SIDE
118 ER	RIGHT NOSE JACK/TIE DOWN FITTING
122 AR	MANUAL DRIVE GEARBOX
122 BR	DOOR CONTROL SWITCH BOX

R
R
R

Exterior Access Doors and Panels, Zone 100
Lower Half of Fuselage, Forward Right Side
Figure 6

EFFECTIVITY: ALL



NOTE
RIGHT SIDE SHOWN

ACCESS IDENTIFICATION NUMBER	ACCESS TO
148A	LOWER AFTERBODY STRUCTURE



ACCESS IDENTIFYING NUMBER	ACCESS TO	ACCESS IDENTIFYING NUMBER	ACCESS TO
191A	LOWER LEFT FUSELAGE, FS 737.5 TO FS 789.0	195F	LOWER FUSELAGE, FS 1403.0 TO FS 1443.0
191B	LOWER LEFT FUSELAGE, FS 789.0 TO FS 865.0	195G	LOWER FUSELAGE, FS 1363.0 TO FS 1480.0
191C	LOWER LEFT FUSELAGE, FS 865.0 TO FS 901.0	195H	LOWER FUSELAGE, FS 1443.0 TO FS 1480.0
191D	LOWER LEFT FUSELAGE, FS 901.0 TO FS 943.0	195J	LOWER FUSELAGE, FS 1480.2 TO FS 1523.4
191E	LOWER LEFT FUSELAGE, FS 943.0 TO FS 983.0	195K	LOWER FUSELAGE, FS 1523.4 TO FS 1605.0
191F	LOWER LEFT FUSELAGE, FS 943.0 TO FS 983.0	195L	LOWER FUSELAGE, FS 1605.0 TO FS 1665.0
193A	LOWER FUSELAGE SKIN, FS 983.0 TO FS 1043.0	197A	UPPER WING TO FUS, FS 943.0 TO FS 983.0
193B	ADF ANTENNA HOUSING, FS 1043.0 TO FS 1103.0	197B	UPPER WING TO FUS, FS 983.0 TO FS 1096.4
193C	LOWER FUSELAGE SKIN, FS 1043.0 TO FS 1103.0	197C	UPPER WING TO FUS, FS 1096.4 TO FS 1212.8
193D	LOWER FUSELAGE SKIN, FS 1103.0 TO FS 1163.0	197D	UPPER WING TO FUS, FS 1212.8 TO FS 1263.2
193E	LOWER FUSELAGE SKIN, FS 1103.0 TO FS 1210.9	197D-1	UPPER WING TO FUS, FS 1263.2 TO FS 1323.1
193F	GROUND CONTROL FOR MLG DOORS	197E	UPPER WING TO FUS, FS 1323.1 TO FS 1480.2
195A	LOWER FUSELAGE SKIN, FS 1393.0 TO FS 1403.0	197F	LOWER WING TO FUS, FS 983.0 TO FS 1103.0
195B	LOWER FUSELAGE SKIN, FS 1263.0 TO FS 1403.0	197G	LOWER WING TO FUS, FS 1103.0 TO FS 1210.9
195C	LOWER FUSELAGE SKIN, FS 1403.0 TO FS 1443.0	197H	LOWER WING TO FUS, FS 1210.9 TO FS 1263.0
195D	ATM REMOVE/INSPECT, FS 1403.0 TO FS 1443.0	197J	LOWER WING TO FUS, FS 1263.0 TO FS 1363.0
195E	ATM SERVICE/INSPECT, FS 1403.0 TO FS 1443.0	197K	LOWER WING TO FUS, FS 1363.0 TO FS 1403.0
		197L	LOWER WING TO FUS, FS 1403.0 TO FS 1480.2

M1-0104-06-022

Exterior Access Doors and Panels, Zone 190
Fairings and Fillets, Left Side
Figure 8



ACCESS IDENTIFYING NUMBER	ACCESS TO	ACCESS IDENTIFYING NUMBER	ACCESS TO
191A	LOWER LEFT FUSELAGE, FS 737.5 TO FS 789.0	195F	LOWER FUSELAGE, FS 1403.0 TO FS 1443.0
191B	LOWER LEFT FUSELAGE, FS 789.0 TO FS 865.0	195G	LOWER FUSELAGE, FS 1363.0 TO FS 1480.0
191C	LOWER LEFT FUSELAGE, FS 865.0 TO FS 901.0	195H	LOWER FUSELAGE, FS 1443.0 TO FS 1480.0
191D	LOWER LEFT FUSELAGE, FS 901.0 TO FS 943.0	195J	LOWER FUSELAGE, FS 1480.2 TO FS 1523.4
191E	LOWER LEFT FUSELAGE, FS 943.0 TO FS 963.0	195K	LOWER FUSELAGE, FS 1523.4 TO FS 1605.0
191F	LOWER LEFT FUSELAGE, FS 943.0 TO FS 983.0	195L	LOWER FUSELAGE, FS 1605.0 TO FS 1665.0
191FA	MESC EXHAUST VALVE ACCESS	197A	UPPER WING TO FUS, FS 943.0 TO FS 983.0
193A	LOWER FUSELAGE SKIN, FS 983.0 TO FS 1043.0	197B	UPPER WING TO FUS, FS 983.0 TO FS 1096.4
193B	ADF ANTENNA HOUSING, FS 1043.0 TO FS 1103.0	197C	UPPER WING TO FUS, FS 1096.4 TO FS 1212.8
193C	LOWER FUSELAGE SKIN, FS 1043.0 TO FS 1103.0	197D	UPPER WING TO FUS, FS 1212.8 TO FS 1263.2
193D	LOWER FUSELAGE SKIN, FS 1103.0 TO FS 1165.0	197D-1	UPPER WING TO FUS, FS 1263.2 TO FS 1323.1
193E	LOWER FUSELAGE SKIN, FS 1103.0 TO FS 1210.9	197E	UPPER WING TO FUS, FS 1323.1 TO FS 1480.2
193F	GROUND CONTROL FOR MLG DOORS	197F	LOWER WING TO FUS, FS 983.0 TO FS 1103.0
195A	LOWER FUSELAGE SKIN, FS 1393.0 TO FS 1403.0	197G	LOWER WING TO FUS, FS 1103.0 TO FS 1210.9
195B	LOWER FUSELAGE SKIN, FS 1363.0 TO FS 1403.0	197H	LOWER WING TO FUS, FS 1210.9 TO FS 1283.0
195C	LOWER FUSELAGE SKIN, FS 1403.0 TO FS 1443.0	197J	LOWER WING TO FUS, FS 1283.0 TO FS 1363.0
195D	ATM REMOVE/INSPECT, FS 1403.0 TO FS 1443.0	197K	LOWER WING TO FUS, FS 1363.0 TO FS 1403.0
195E	ATM SERVICE/INSPECT, FS 1403.0 TO FS 1443.0	197L	LOWER WING TO FUS, FS 1403.0 TO FS 1480.2

M1-0100-06-214

Exterior Access Doors and Panels, Zone 190
Fairings and Fillets, Left Side
Figure 8



ACCESS IDENTIFYING NUMBER	ACCESS TO	ACCESS IDENTIFYING NUMBER	ACCESS TO
192A	LOWER FUSELAGE, FS 737.5 TO FS 794.6	196C	LOWER FUSELAGE SKIN, FS 1403.0 TO FS 1443.0
192B	LOWER FUSELAGE, FS 794.6 TO FS 828.3	196D	ATM REMOVAL/INSPECTION FS 1403.0 TO FS 1443.0
192C	GALLEY DOOR OUTER SKIN, FS 793.62 TO FS 828.38	196E	ATM SERVICING/INSPECTION, FS 1403.0 TO FS 1443.0
192D	LOWER FUSELAGE, FS 828.3 TO FS 865.0	196F	LOWER FUSELAGE, FS 1403.0 TO FS 1443.0
192E	LOWER FUSELAGE, FS 865.0 TO FS 883.0	196G	LOWER FUSELAGE FS 1363.0 TO FS 1445.0
192F	POTABLE WATER SERVICE DOOR, FS 883.0 TO FS 901	196H	LOWER FUSELAGE, FS 1480.2 TO FS 1545.0
192G	LOWER FUSELAGE, FS 865.0 TO FS 901.0	196K	CENTER CARGO COMPARTMENT DOOR SKIN, FS 1551.9 TO FS 1625.0
192H	LOWER FUSELAGE, FS 901.0 TO FS 943.0	196L	LOWER FUSELAGE, FS 1605.0 TO FS 1665.0
192J	LOWER FUSELAGE, FS 943.0 TO FS 963.0	198A	UPPER WING TO FUSELAGE, FS 943.0 TO FS 983.0
192K	MID-ELECTRICAL SERVICE CENTER ACCESS DOOR	198B	UPPER WING TO FUSELAGE, FS 983.0 TO FS 1103.0
192L	LOWER FUSELAGE, FS 943.0 TO FS 983.0	198C	UPPER WING TO FUSELAGE, FS 1103.0 TO FS 1210.9
194A	LOWER FUSELAGE, FS 983.0 TO FS 1043.0	198D	UPPER WING TO FUSELAGE, FS 1210.9 TO FS 1323.1
194B	LOWER FUSELAGE, FS 1043.0 TO FS 1103.0	198E	UPPER WING TO FUSELAGE, FS 1323.1 TO FS 1480.2
194C	ADF ANTENNA HOUSING, FS 1043.0 TO FS 1103.0	198F	LOWER WING TO FUSELAGE, FS 983.0 TO FS 1103.0
194D	LOWER FUSELAGE, FS 1103.0 TO FS 1163.0	198G	LOWER WING TO FUSELAGE, FS 1103.0 TO FS 1210.9
194E	LOWER FUSELAGE, FS 1163.0 TO FS 1210.9	198H	LOWER WING TO FUSELAGE, FS 1210.9 TO FS 1283.0
194F	GROUND CONTROL FOR MLG DOORS	198J	LOWER WING TO FUSELAGE, FS 1283.0 TO FS 1363.0
196A	LOWER FUSELAGE SKIN, FS 1383.0 TO FS 1403.0	198K	LOWER WING TO FUSELAGE, FS 1363.0 TO FS 1403.0
196B	LOWER FUSELAGE SKIN, FS 1363.0 TO FS 1403.0	198L	LOWER WING TO FUSELAGE, FS 1403.0 TO FS 1480.2

M1-0103-06-021

Exterior Access Doors and Panels, Zone 190
Fairings and Fillets, Right Side
Figure 9



BOTTOM VIEW LOOKING UP

ACCESS IDENTIFICATION NUMBER	ACCESS TO
316AB	AFTERBODY WASHOUT OPENING
316BB	AFT PITCH COUPLER; STABILIZER CONTROL LINKAGE AND SERVO PLUMBING, LEFT SIDE
316CB	STABILIZER CONTROL LINKAGE AND SERVO PLUMBING, RIGHT SIDE
316DB	STABILIZER AUTOPILOT SERVO
317AB	STABILIZER SERVO, LEFT
317BB	HORIZONTAL STABILIZER ACTUATORS; FIRE EXTINGUISHING BOTTLES; PITCH ELECTRICAL FEEL/TRIM ASSY
317CB	STABILIZER SERVO RIGHT; PITCH MECHANICAL FEEL/TRIM ASSEMBLY
317DL	BLEED AIR SYSTEM DUCT
317ER	APU ACCESS
318AL	PIVOT BEARING, LEFT
318AR	PIVOT BEARING, RIGHT
318BA	TAIL SKID SERVICING
318BB	INTERPHONE JACK AND LIGHT SWITCH
319AL	APU COMPARTMENT
319BR	APU COMPARTMENT
319CL	APU COMPARTMENT
319DR	APU SERVICING

MI-0006-06-007

R Exterior Access Doors and Panels, Zone 300 Empennage and Afterbody
R Figure 10



ACCESS IDENT. NUMBER LEFT	ACCESS TO
311KL	INLET ANTI-ICING RING FRAME
311NL	INLET ANTI-ICING RING FRAME
311RL	INLET ANTI-ICING RING FRAME
311UL	S-DUCT TO INLET MOUNT BOLTS
311VL	S-DUCT TO INLET MOUNT BOLTS
313A	CENTER ENGINE AIR INLET MOUNT BOLTS;
313A-1	ANTI-ICING DUCTING; S-DUCT ATTACH BOLTS
313CL	ANTI-ICING DUCT INSPECTION AND REPAIR
313DL	DORSAL SADDLE MOUNT BOLTS
313EL	S-DUCT SUPPORT BOLTS
313GT	HIGH-FREQUENCY ANTENNA
314AL	STRUCTURE
315AL	S-DUCT TO INLET MOUNT BOLT
315BL	FILLET AREA, CENTER ENGINE INLET TO FUSELAGE

ACCESS IDENT. NUMBER LEFT	ACCESS TO
318AL	STARTER CONTROL VALVE
318BL	HORIZONTAL STABILIZER PIVOT BEARING AREA
318BL-1	PIVOT BEARING LUBRICATION
318EL	HORIZONTAL STABILIZER PIVOT BEARING AND FAIRING CLOSURE ASSEMBLY
318FL	APU LOAD COMPRESSOR AIR INLET ACTUATOR
318GL	STRUCTURE AND SYSTEMS INSPECTION
337A	AIRGATE REMOVE AND ATTACH
337ST	AIRGATE REMOVE AND ATTACH
337CT	AIRGATE FAIRING ATTACHMENT
337DT	AIRGATE FAIRING ATTACHMENT
337BB	AIRGATE REMOVE AND ATTACH
337CB	AIRGATE FAIRING ATTACHMENT
337DB	AIRGATE FAIRING ATTACHMENT

M1-0004-06-06

R Exterior Access Doors and Panels, Zone 300 Afterbody, Left Side
R Figure 11



RIGHT SIDE

ACCESS IDENT. NUMBER	ACCESS TO
311AR	INLET ANTI-ICING RING FRAME
311DR	INLET ANTI-ICING RING FRAME
311GR	INLET ANTI-ICING RING FRAME
311UR	S-DUCT TO INLET MOUNT BOLTS
311VR	S-DUCT TO INLET MOUNT BOLTS
313A-2	ANTI-ICING DUCTING, S-DUCT ATTACH BOLTS
313DR	DORSAL SADDLE MOUNT BOLTS
313EP	S-DUCT SUPPORT BOLTS
313FR	INTERNAL AREAS OF UPPER AFTERBODY (HF ANTENNA AND TUNER ACCESS-INSTALLED OR PROVISIONS)
314AR	STRUCTURAL INSPECTION

ACCESS IDENT. NUMBER	ACCESS TO
315AR	S-DUCT TO INLET MOUNT BOLTS
315BR	FILLET AREA, CENTER ENGINE INLET TO FUSELAGE
317ER	APU EXHAUST SHROUD
318AR	STRUCTURE AND SYSTEMS INSPECTION
318BR	HORIZONTAL STABILIZER PIVOT BEARING AREA
318BR-1	PIVOT BEARING LUBRICATION AND INSPECTION
318ER	HORIZONTAL STABILIZER PIVOT BEARING AND FAIRING CLOSURE ASSEMBLY
318FR	APU COMPARTMENT VENT LINE
318GR	STRUCTURE AND SYSTEMS INSPECTION
318HR	ELEVATOR INBOARD GAP FAIRING
347A	AIRGATE REMOVE AND ATTACH
347BB	AIRGATE REMOVE AND ATTACH
347BT	AIRGATE REMOVE AND ATTACH
347CB	AIRGATE FAIRING ATTACHMENT
347CT	AIRGATE FAIRING ATTACHMENT
347DB	AIRGATE FAIRING ATTACHMENT
347DT	AIRGATE FAIRING ATTACHMENT

M1-0008-06-044

R Exterior Access Doors and Panels, Zone 300
R Afterbody, Right Side
R Figure 12



LEFT SIDE BOTTOM VIEW LOOKING UP
RIGHT SIDE OPPOSITE

ACCESS IDENTIFICATION NUMBER		ACCESS TO
LEFT	RIGHT	
331A	341A	HORIZ STAB. LEADING EDGE
331B	341B	HORIZ STAB. LEADING EDGE
331C	341C	HORIZ STAB. LEADING EDGE
331D	341D	HORIZ STAB. LEADING EDGE
331E	341E	HORIZ STAB. LEADING EDGE
331F	341F	HORIZ STAB. LEADING EDGE
331G	341G	HORIZ STAB. LEADING EDGE
331H	341H	HORIZ STAB. LEADING EDGE
333AB	343AB	HORIZ STAB. STRUCTURE
333BB	343BB	HORIZ STAB. STRUCTURE
333CB	343CB	HORIZ STAB. STRUCTURE
333DB	343DB	HORIZ STAB. STRUCTURE
333EB	343EB	HORIZ STAB. STRUCTURE
333FB	343FB	HORIZ STAB. STRUCTURE
333GB	343GB	HORIZ STAB. OUTER BOX
334AT	344AT	HORIZ STAB. TO AFTERBODY SEAL
334AB	344AB	HORIZ STAB. TO AFTERBODY SEAL
334CB	344CB	ELEV DRIVE MECHANISM; ELEV AFT DRIVE QUADRANT; HINGE BEARING
334EB	344EB	ELEVATOR HINGE BEARING

ACCESS IDENTIFICATION NUMBER		ACCESS TO
LEFT	RIGHT	
334FB	344FB	ELEVATOR HINGE BEARING
334GB	344GB	HORIZ STAB. TRAILING EDGE
334HB	344HB	ELEV HINGE BEARING, CBAL WEIGHT
334JB	344JB	ELEV HINGE BEARING, CBAL WEIGHT
334KB	344KB	COUNTERBALANCE WEIGHT
334LB	344LB	ELEV HINGE BEARING, CBAL WEIGHT
334MB	344MB	ELEV HINGE BEARING, CBAL WEIGHT
334NB	344NB	COUNTERBALANCE WEIGHT
334PB	344PB	ELEV HINGE BEARING, CBAL WEIGHT
334QB	344QB	ELEV HINGE BEARING, CBAL WEIGHT
334RB	344RB	COUNTERBALANCE WEIGHT
334SB	344SB	ELEV HINGE BEARING, CBAL WEIGHT
334TB	344TB	ELEV HINGE BEARING, CBAL WEIGHT
334UB	344UB	ELEV HINGE BEARING, CBAL WEIGHT
334VB	344VB	ELEV HINGE BEARING, CBAL WEIGHT
334WB	344WB	ELEV HINGE BEARING, CBAL WEIGHT
335AB	345AB	ELEV HINGE BEARING
335BB	345BB	ELEVATOR HINGE BEARING
335CB	345CB	ELEVATOR HINGE BEARING
335DB	345DB	ELEV PUSHROD ROD END
336A	346A	HORIZ STAB. CLOSURE RIB
336B	346B	HORIZ STAB. TRAILING EDGE

M1-0105-06-005

Exterior Access Doors and Panels, Zone 300
Horizontal Stabilizer and Elevator
Figure 13



ACCESS IDENTIFICATION NUMBER		ACCESS TO
LEFT	RIGHT	
321A		VERTICAL STAB. FRONT SPAR
321B		VERTICAL STAB. FRONT SPAR
321C		VERTICAL STAB. FRONT SPAR
321D		VERTICAL STAB. FRONT SPAR
323A		VERTICAL STAB. FRONT SPAR
323BL	323BR	VOR ANTENNA AND COUPLER
323C		TIP AREA
324AL	324AR	RUDDER HINGE, FUNCTIONAL COMPONENTS
324BL	324BR	VERTICAL STAB. REAR SPAR
324CL	324CR	RUDDER HINGE, DAMPER
324DL	324DR	VERTICAL STAB. REAR SPAR
324EL	324ER	RUDDER HINGE, DAMPER
324FL	324FR	VERTICAL STAB. REAR SPAR
324GL	324GR	RUDDER HINGE, DAMPER
324HL	324HR	VERTICAL STAB. REAR SPAR
324JL	324JR	RUDDER HINGE, DAMPER
324KL	324KR	VERTICAL STAB. REAR SPAR

ACCESS IDENTIFICATION NUMBER		ACCESS TO
LEFT	RIGHT	
324LL	324LR	RUDDER HINGE
325AL	325AR	RUDDER BASE REMOVAL CLEARANCE
325CL	325CR	RUDDER HINGE BEARING
325DL	325DR	RUDDER HINGE BEARING
325EL	325ER	RUDDER HINGE BEARING
325FL	325FR	RUDDER HINGE BEARING
325GL	325GR	RUDDER HINGE BEARING
325HL	325HR	RUDDER HINGE BEARING
325K		TOP RUDDER CLOSURE RIB
325L		TOP RUDDER CLOSURE RIB
325ML	325MR	CBAL BEAM ATTACH, INSPECTION
325NL	325NR	CBAL BEAM ATTACH, INSPECTION
325PL	325PR	CBAL BEAM ATTACH, INSPECTION
325QL	325QR	CBAL BEAM ATTACH, INSPECTION
326AL	326AR	RUDDER TRAILING EDGE
326BL	326BR	RUDDER
326C		COUNTER BALANCE

M1-0104-06-005

R R R Exterior Access Doors and Panels, Zone 300
Vertical Stabilizer and Rudder
Figure 14

EFFECTIVITY: ALL

D011B



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411KL	421KL	INLET ANTI-ICING RING FRAME
411ML	421ML	INLET ANTI-ICING RING FRAME
411PL	421PL	INLET ANTI-ICING RING FRAME
411QL	421QL	INLET ANTI-ICING RING FRAME
411SL	421SL	FIRE EXTINGUISHER BOTTLE
411TL	421TL	FIRE EXTINGUISHER BOTTLE
411UL	421UL	VENTILATION SHUT OFF VALVE
413A	423A	ENGINE ACCESSORIES
413B	423B	OIL FILTER AND SERVICING
413C	423C	STARTER OIL PRESSURE FILLER
413D	423D	IDG OIL PRESSURE FILLER
417A	427A	TURBINE SECTION
418DL	428DL	AIR MOTOR
451AT	461AT	NOSE FAIRING, FWD
451BT	461BT	PYLON
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON
452CT	462CT	TEMPERATURE SENSOR

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452DL	462DL	REAR ENGINE MOUNT
452EL	462EL	PYLON
452FL	462FL	PYLON MOUNT BOLT
453AL	463AL	DRAG LINK BOLT
453B	463B	SCREWJACK AND GEARBOX
453C	463C	PYLON FAIRING
	463DL	HYDRAULIC COMPONENTS
	463EL	HYDRAULIC FILTER POPOUT INDICATOR
453GL	463GL	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JL	463JL	SKIRT FAIRING

M1-0105-06-399

Exterior Access Doors and Panels, Zone 400
Power Plant and Plyon, Left Side
Figure 15

R EFFECTIVITY: WITH N-14 AFTERBODY
R
001B



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411KL	421KL	INLET ANTI-ICING RING FRAME
411ML	421ML	INLET ANTI-ICING RING FRAME
411PL	421PL	INLET ANTI-ICING RING FRAME
411QL	421QL	INLET ANTI-ICING RING FRAME
411SL	421SL	FIRE EXTINGUISHER BOTTLE
411TL	421TL	FIRE EXTINGUISHER BOTTLE
411UL	421UL	VENTILATION SHUT OFF VALVE
413A	423A	ENGINE ACCESSORIES
413B	423B	OIL FILTER AND SERVICING
413C	423C	STARTER OIL PRESSURE FILLER
413D	423D	IDG OIL PRESSURE FILLER
417A	427A	TURBINE SECTION
418DL	428DL	AIR MOTOR
451AT	461AT	NOSE FAIRING, FWD
451BT	461BT	PYLON
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON
452CT	462CT	TEMPERATURE SENSOR

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452DL	462DL	REAR ENGINE MOUNT
452EL	462EL	PYLON
452FL	462FL	PYLON MOUNT BOLT
453AL	463AL	DRAG LINK BOLT
453B	463B	GEARBOX
453C	463C	PYLON FAIRING
	463DL	HYDRAULIC COMPONENTS
	463EL	HYDRAULIC FILTER POPOUT INDICATOR
453GL	463GL	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JL	463JL	SKIRT FAIRING

M1-0101-06-201

R Exterior Access Doors and Panels, Zone 400
R Power Plant and Pylon, Left Side
R Figure 15

EFFECTIVITY: WITH 11-DEGREE AFTERBODY

001B



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411KL	421KL	INLET ANTI-ICING RING FRAME
411ML	421ML	INLET ANTI-ICING RING FRAME
411PL	421PL	INLET ANTI-ICING RING FRAME
411QL	421QL	INLET ANTI-ICING RING FRAME
411SL	421SL	FIRE EXTINGUISHER BOTTLE
411TL	421TL	FIRE EXTINGUISHER BOTTLE
411UL	421UL	VENTILATION SHUT OFF VALVE
413A	423A	ENGINE ACCESSORIES
413B	423B	OIL FILTER AND SERVICING
413C	423C	STARTER OIL PRESSURE FILLER
413D	423D	IDG OIL PRESSURE FILLER
417A	427A	TURBINE SECTION
418DL	428DL	AIR MOTOR
451AT	461AT	NOSE FAIRING, FWD
451BT	461BT	PYLON
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON
452CT	462CT	TEMPERATURE SENSOR

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452DL	462DL	REAR ENGINE MOUNT
452EL	462EL	PYLON
452FL	462FL	PYLON MOUNT BOLT
453AL	463AL	DRAG LINK BOLT
453B	463B	GEARBOX
453C	463C	PYLON FAIRING
	463DL	HYDRAULIC COMPONENTS
	463EL	HYDRAULIC FILTER POPOUT INDICATOR
453GL	463GL	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JL	463JL	SKIRT FAIRING

AU-0402-00-202

R
R
R

Exterior Access Doors and Panels, Zone 400
Power Plant and Pylon, Left Side
Figure 15

EFFECTIVITY: WITH 15-DEGREE AFTERBODY

001B



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411BR	421BR	INLET ANTI-ICING RING FRAME
411DR	421DR	INLET ANTI-ICING RING FRAME
411FR	421FR	INLET ANTI-ICING RING FRAME
411HR	421HR	INLET ANTI-ICING RING FRAME
411RR	421RR	THERMAL ANTI-ICING VALVE
414A	424A	ACCESSORY SECTION
414B	424B	STARTER
417A	427A	TURBINE SECTION
418CT	428CT	SCREWJACK, PROXIMITY SENSOR
418DR	428DR	SCREWJACK
419DR	428DR	AIR MOTOR
451AT	461AT	NOSE FAIRING FWD
451AT-1	461AT-1	P1 PROBE
451BT	461BT	ELECTRICAL AND HYDRAULIC CONNECTIONS

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON, CABLE TENSION REGULATOR
452CT	462CT	PYLON, TEMPERATURE SENSOR
452DR	462DR	REAR ENGINE MOUNT
452ER	462ER	PYLON
452FR	462FR	PYLON MOUNT BOLT
453AR	463AR	DRAG LINK BOLT
453B	463B	SCREWJACK AND GEARBOX
453C	463C	PYLON FAIRING
453DR		HYDRAULIC COMPONENTS
453ER		HYDRAULIC FILTER POPOUT INDICATOR
453GR	463GR	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JR	463JR	SKIRT FAIRING

mi-0108-00-000

R
R
R

Exterior Access Doors and Panels, Zone 400
Power Plant and Pylon, Right Side
Figure 16

EFFECTIVITY: WITH N-14 AFTERBODY

001B



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411BR	421BR	INLET ANTI-ICING RING FRAME
411DR	421DR	INLET ANTI-ICING RING FRAME
411FR	421FR	INLET ANTI-ICING RING FRAME
411HR	421HR	INLET ANTI-ICING RING FRAME
411RR	421RR	THERMAL ANTI-ICING VALVE
414A	424A	ACCESSORY SECTION
414B	424B	STARTER
417A	427A	TURBINE SECTION
418DR	428DR	AIR MOTOR
451AT	461AT	NOSE FAIRING FWD
451AT-1	461AT-1	P1 PROBE
451BT	461BT	ELECTRICAL AND HYDRAULIC CONNECTIONS

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON, CABLE TENSION REGULATOR
452CT	462CT	PYLON, TEMPERATURE SENSOR
452DR	462DR	REAR ENGINE MOUNT
452ER	462ER	PYLON
452FR	462FR	PYLON MOUNT BOLT
453AR	463AR	DRAG LINK BOLT
453B	463B	GEARBOX
453C	463C	PYLON FAIRING
453DR		HYDRAULIC COMPONENTS
453ER		HYDRAULIC FILTER POPOUT INDICATOR
453GR	463GR	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JR	463JR	SKIRT FAIRING

R
R
R

Exterior Access Doors and Panels, Zone 400,
Power Plant and Pylon, Right Side
Figure 16

EFFECTIVITY: WITH 11-DEGREE AFTERBODY

0018



ACCESS IDENTIFICATION NUMBER		ACCESS TO
411BR	421BR	INLET ANTI-ICING RING FRAME
411DR	421DR	INLET ANTI-ICING RING FRAME
411FR	421FR	INLET ANTI-ICING RING FRAME
411HR	421HR	INLET ANTI-ICING RING FRAME
411RR	421RR	THERMAL ANTI-ICING VALVE
414A	424A	ACCESSORY SECTION
414B	424B	STARTER
417A	427A	TURBINE SECTION
418DR	428DR	AIR MOTOR
451AT	461AT	NOSE FAIRING FWD
451AT-1	461AT-1	PT PROBE
451BT	461BT	ELECTRICAL AND HYDRAULIC CONNECTIONS

ACCESS IDENTIFICATION NUMBER		ACCESS TO
452AT	462AT	CABLE TENSION REGULATOR
452BT	462BT	PYLON, CABLE TENSION REGULATOR
452CT	462CT	PYLON, TEMPERATURE SENSOR
452DR	462DR	REAR ENGINE MOUNT
452ER	462ER	PYLON
452FR	462FR	PYLON MOUNT BOLT
453AR	463AR	DRAG LINK BOLT
453B	463B	GEARBOX
453C	463C	PYLON FAIRING
453DR		HYDRAULIC COMPONENTS
453ER		HYDRAULIC FILTER POPOUT INDICATOR
453GR	463GR	PYLON MOUNT BOLT
453H	463H	PYLON FAIRING
453JR	463JR	SKIRT FAIRING

M1-0101-00-204

R
R
R

Exterior Access Doors and Panels, Zone 400
Power Plant and Pylon, Right Side
Figure 16

EFFECTIVITY: WITH 15-DEGREE AFTERBODY

001B



ACCESS IDENTIFYING NUMBER	ACCESS IDENTIFYING NUMBER	ACCESS TO
LEFT	RIGHT	
433AL	434AR	ENGINE, STARTER, IDG, ACCESSORIES, TAIL SKID
433BL	434BR	ENGINE, ACCESSORIES, STARTER, IDG, HYDRAULIC PUMPS
433CL	434CR	ENGINE REMOVAL/INSTALLATION
433DL	434DR	ENGINE ACCESSORIES, CONTROLS
433EL	434ER	MID FIXED COWL ATTACH BOLTS
435AL	435AR	COMBUSTION SECTION, UPPER FAIRING
435BL	435BR	REAR COWL PANEL
438CT		THRUST REVERSER SCREWJACK, GEARBOX
438DB		THRUST REVERSER SCREWJACK, GEARBOX
438DL	438DR	AIR MOTOR
471AL	471AR	CABLE TENSION REGULATOR
471BL		ENGINE SUPPORT STRUCTURE, PRESSURE SWITCH
	471BR	ENGINE MOUNT
471CL		ENGINE MOUNT
	471CR	AIR INLET CONTROL VALVE
471DL		AIR INLET CONTROL VALVE
	471DR	ENGINE REAR MOUNT
471EL		ENGINE REAR MOUNT
472AL	472AR	FAIRING INSTALLATION, UPPER ENGINE SUPPORT STRUCTURE
472BL	472BR	FAIRING INSTALLATION, AFT ENGINE SUPPORT STRUCTURE
472C		ENGINE REMOVAL/INSTALLATION
472CL	472CR	BOOTSTRAP INSTALLATION
472DL	472DR	GLOVE FAIRING ATTACH PIN

M1-0[illegible]-05-006

Exterior Access Doors and Panels, Zone 400, No. 2 Power Plant
Figure 17



ACCESS IDENTIFYING NUMBER	ACCESS IDENTIFYING NUMBER	ACCESS TO
LEFT	RIGHT	
433AL	434AR	ENGINE, STARTER, IDG, ACCESSORIES, TAIL SKID
433BL	434BR	ENGINE, ACCESSORIES, STARTER, IDG, HYDRAULIC PUMPS
433CL	434CR	ENGINE REMOVAL/INSTALLATION
433DL	434DR	ENGINE ACCESSORIES, CONTROLS
433EL	434ER	MID FIXED COWL ATTACH BOLTS
435AL	435AR	COMBUSTION SECTION, UPPER FAIRING
435BL	435BR	REAR COWL PANEL
436A		BOTTOM COWL PANEL
436DL		AIR MOTOR
471AL		CABLE TENSION REGULATOR
471BL		ENGINE SUPPORT STRUCTURE, PRESSURE SWITCH
	471BR	ENGINE MOUNT
471CL		ENGINE MOUNT
	471CR	AIR INLET CONTROL VALVE
471DL		AIR INLET CONTROL VALVE
	471DR	ENGINE REAR MOUNT
471EL		ENGINE REAR MOUNT
472AL	472AR	FAIRING INSTALLATION, UPPER ENGINE SUPPORT STRUCTURE
472BL	472BR	FAIRING INSTALLATION, AFT ENGINE SUPPORT STRUCTURE
472C		ENGINE REMOVAL/INSTALLATION
472CL	472CR	BOOTSTRAP INSTALLATION
472DL	472DR	GLOVE FAIRING ATTACH PIN

M1-[illegible]

Exterior Access Doors and Panels, Zone 400, No. 2 Power Plant
Figure 17



ACCESS IDENTIFYING NUMBER	ACCESS IDENTIFYING NUMBER	ACCESS TO
LEFT	RIGHT	
433AL	433AR	ENGINE, STARTER, IDG, ACCESSORIES, TAIL SKID
433BL	434BR	ENGINE, ACCESSORIES, STARTER, IDG, HYDRAULIC PUMPS
433CL	434CR	ENGINE REMOVAL/INSTALLATION
433DL	434DR	ENGINE ACCESSORIES, CONTROLS
433EL	434ER	MID FIXED COWL ATTACH BOLTS
435AL	435AR	COMBUSTION SECTION, UPPER FAIRING
435BL	435BR	REAR COWL PANEL
436A		BOTTOM COWL PANEL
438DL	438DR	AIR MOTOR
471AL	471AR	CABLE TENSION REGULATOR
471BL		ENGINE SUPPORT STRUCTURE, PRESSURE SWITCH
	471BR	ENGINE MOUNT
471CL		ENGINE MOUNT
	471CR	AIR INLET CONTROL VALVE
471DL		AIR INLET CONTROL VALVE
	471DR	ENGINE REAR MOUNT
471EL		ENGINE REAR MOUNT
472AL	472AR	FAIRING INSTALLATION, UPPER ENGINE SUPPORT STRUCTURE
472BL	472BR	FAIRING INSTALLATION, AFT ENGINE SUPPORT STRUCTURE
472C		ENGINE REMOVAL/INSTALLATION
472CL	472CR	BOOTSTRAP INSTALLATION
472DL	472DR	GLOVE FAIRING ATTACH PIN

MI-0100-06-206

Exterior Access Doors and Panels, Zone 400, No. 2 Power Plant
Figure 17



ACCESS IDENTIFYING NUMBER	ACCESS IDENTIFYING NUMBER	ACCESS TO
LEFT	RIGHT	
433AL	434AR	ENGINE, STARTER, IDG, ACCESSORIES, TAIL SKID
433BL	434BR	ENGINE, ACCESSORIES, STARTER, IDG, HYDRAULIC PUMPS
433CL	434CR	ENGINE REMOVAL/INSTALLATION
433DL	434DR	ENGINE ACCESSORIES, CONTROLS
433EL	434ER	MID FIXED COWL ATTACH BOLTS
435AL	435AR	COMBUSTION SECTION, UPPER FAIRING
435BL	435BR	REAR COWL PANEL
436A		BOTTOM COWL PANEL
438DL	438DR	AIR MOTOR
471AL		ENGINE ISOLATION VALVE
471AL-1		ENGINE ISOLATION VALVE (MANUAL CONTROL ACCESS)
	471AR	CABLE TENSION REGULATOR
471BL		ENGINE SUPPORT STRUCTURE, PRESSURE SWITCH
	471BR	ENGINE MOUNT
471CL		ENGINE MOUNT
	471CR	AIR INLET CONTROL VALVE
471DL		AIR INLET CONTROL VALVE
	471DR	ENGINE REAR MOUNT
471EL		ENGINE REAR MOUNT
472AL	472AR	FAIRING INSTALLATION, UPPER ENGINE SUPPORT STRUCTURE
472BL	472BR	FAIRING INSTALLATION, AFT ENGINE SUPPORT STRUCTURE
472C		ENGINE REMOVAL/INSTALLATION
472CL	472CR	BOOTSTRAP INSTALLATION
472DL	472DR	GLOVE FAIRING ATTACH PIN

M1-0000-00-432

R Exterior Access Doors and Panels, Zone 400, No. 2 Power Plant
R Figure 17

R EFFECTIVITY: WITH SB53-227
R
0018



Exterior Access Doors and Panels, Zones 500 and 600
Wing Bottom Surface
Figure 18 (Sheet 1)

R 2 001B

EFFECTIVITY: ALL

ACCESS IDENTIFICATION NUMBER		ACCESS TO: ⚠
LEFT	RIGHT	⚠ SLAT DRIVE IS ALONG ENTIRE LEADING EDGE
611AB	611AB	SLAT DRIVE RIGHT ANGLE GEARBOX, PNEUMATIC DUCT AND AREA OVERHEAT CH D/E
611AB-1	611AB-1	BLOWOUT DOOR
611AB-2	611AB-2	BLOWOUT DOOR
611BB	611BB	TORQUE LIMITING BRAKE, PNEUMATIC DUCT AND AREA OVERHEAT CH D/E
611CB	611CB	INBOARD BALLSCREW ACTUATOR
611CB-1	611CB-1	BLOWOUT DOOR
611CB-2	611CB-2	BLOWOUT DOOR
611DB	611DB	FRONT SPAR
611DB-1	611DB-1	BLOWOUT DOOR
611DB-2	611DB-2	BLOWOUT DOOR
611EB	611EB	FRONT SPAR
611FB	611FB	INBD BALLSCREW ACTUATOR
611FB-1	611FB-1	BLOWOUT DOOR
611FB-2	611FB-2	BLOWOUT DOOR
611GB	611GB	FRONT SPAR
611GB-1	611GB-1	BLOWOUT DOOR
611GB-2	611GB-2	BLOWOUT DOOR
	611GB-3	SPARE ENGINE FORWARD ATTACH FITTING (RIGHT WING ONLY IF INSTALLED)
611HB	611HB	INBOARD BALLSCREW ACTUATOR, ANTI-ICE DUCT AND AREA OVERHEAT CH F/G
611JB	611JB	FRONT SPAR
611JB-1	611JB-1	BLOWOUT DOOR
611JB-2	611JB-2	BLOWOUT DOOR
611KB	611KB	FRONT SPAR
611KB-1	611KB-1	BLOWOUT DOOR
611LB	611LB	ENG ISLN VALVE, SPEED DUCT OVERPRESSURE VALVE, PNEUMATIC DUCT AND AREA OVERHEAT CH D/E, ENG 1/3 TANK VALVE, ANTI-ICE DUCT EXCESS FLOW PROBE
611LB-1	611LB-1	BLOWOUT DOOR
611LB-2	611LB-2	BLOWOUT DOOR
611LB-3	611LB-3	ENG ISOLATION VALVE - MANUAL DEACTIVATION
611MB	611MB	LANDING LIGHT
621AB	621AB	ANTI-ICE TELESCOPING DUCT, AREA OVERHEAT CH F/G
621BB	621BB	ANTI-ICE TELESCOPING CONDUIT
621CB	621CB	OUTBOARD BALLSCREW ACTUATOR
621DB	621DB	FRONT SPAR
621EB	621EB	FRONT SPAR
	621FB	FUELING/DEFUELING PANEL, AND PRESSURE FUELING ADAPTERS
621FB		PRESSURE FUELING ADAPTERS
621GB	621GB	FRONT SPAR
621GB-1	621GB-1	FUEL GROUNDING JACKS, FLOAT VALVE OVERRIDE SWITCHES, AND SERVICE INTERPHONE JACKS
621HB	621HB	TANK 2L/2R FUELING VALVE
621JB	621JB	OUTBD BALLSCREW ACTUATOR
621KB	621KB	FRONT SPAR
621LB	621LB	FRONT SPAR

ACCESS IDENTIFICATION NUMBER		ACCESS TO:
LEFT	RIGHT	
621MB	621MB	FRONT SPAR
621NB	621NB	OUTBD BALLSCREW ACTUATOR
621PB	621PB	FRONT SPAR
621QB	621QB	FRONT SPAR
621RB	621RB	FRONT SPAR
621SB	621SB	OUTBD BALLSCREW ACTUATOR
621TB	621TB	ASYMMETRY BRAKE AND POSITION TRANSMITTER
621UB	621UB	FRONT SPAR
631AB	631AB	TANK 1/3 INTERIOR
	631BB	APU FUEL PUMP (RIGHT WING ONLY IF INSTALLED)
631CB	631CB	TANK 1/3 DUAL BOOST PUMP
631DB	631DB	TANK 1/3 INTERIOR
631EB	631EB	TANK 1/3 INTERIOR
631FB	631FB	TANK 1/3 INTERIOR
632AB	632AB	DUAL BOOST PUMP TANK 2L/2R
632BB	632BB	SURGE BOX TANK 2L/2R, TRANSFER VALVE
632CB	632CB	TANK 2L/2R INBOARD INTERIOR
632DB	632DB	TANK 2L/2R INBOARD INTERIOR
632EB	632EB	TANK 2L/2R INBOARD INTERIOR
632FB	632FB	TANK 2L/2R INBOARD INTERIOR
633AB	633AB	TANK 2L/2R OUTBOARD INTERIOR
633BB	633BB	TANK 2L/2R OUTBOARD INTERIOR
633CB	633CB	TANK 2L/2R OUTBOARD INTERIOR
633DB	633DB	TANK 2L/2R OUTBOARD INTERIOR
633EB	633EB	TANK 2L/2R OUTBOARD INTERIOR
633FB	633FB	TANK 2L/2R OUTBOARD INTERIOR
633GB	633GB	TANK 2L/2R OUTBOARD INTERIOR
633HB	633HB	TANK 2L/2R OUTBOARD INTERIOR
633JB	633JB	TANK 2L/2R OUTBOARD INTERIOR
633KB	633KB	TANK 2L/2R OUTBOARD INTERIOR
634AB	634AB	VENT BOX INTERIOR
635AB	635AB	WING TIP STRUCTURE
635B	635B	WING TIP CAP
635CB	635CB	WING POSITION LIGHT
635DB	635DB	WING TIP PANEL
635EB	635EB	WING TIP STRUCTURE
635FB	635FB	WING TIP STRUCTURE
641AB	641AB	TANK 1/3 FUEL LOW PRESS. SWITCH, DEFUEL VALVE, SYS B & C BRAKE CONTROL MODULE
641AB-1	641AB-1	REAR SPAR TO FLAP AREA
641AB-2	641AB-2	REAR SPAR TO FLAP AREA
641BB	641BB	FLAP ACTUATING GEARBOX
641CB	641CB	NO. 1 SPOILER SERVO CONTROL
641DB	641DB	FLAP ACTUATING GEARBOX
641EB	641EB	AREA TANK 1/3 FUELING VALVE
641EB-1	641EB-1	REAR SPAR TO FLAP AREA
641EB-2	641EB-2	REAR SPAR TO FLAP AREA
641FB	641FB	FLAP ACTUATING GEARBOX, NO. 2 SPOILER SERVO CONTROL
641GB	641GB	FLAP ACTUATING GEARBOX, DEFUEL VALVE
641GB-1	641GB-1	FUEL PUMP PRESS. SWITCH
641GB-2	641GB-2	REAR SPAR TO FLAP AREA

ACCESS IDENTIFICATION NUMBER		ACCESS TO:
LEFT	RIGHT	
651AB	651AB	INBOARD AILERON, DUAL AILERON POSITION TRANSDUCER (L WING)
651BB	651BB	INBOARD AILERON ACTUATOR & CONTROL MODULE, INTERPHONE JACK
651BB-1	651BB-1	REAR SPAR TO INBOARD AILERON
651CB	651CB	INBOARD AILERON POSITION TRANSMITTER
661BB	661BB	FLAP ACTUATING GEARBOX, NO. 3 & 4 SPOILER CONTROL SERVOS AND CONTROL SELECTOR
661CB	661CB	FLAP ACTUATING GEARBOX, NO. 5 & 6 SPOILER CONTROL SERVOS
671AB	671AB	OUTBOARD AILERON ACTUATOR & FLAP ASYMMETRY BRAKE, JETTISON VALVE (IF INSTALLED)
671AB-1	671AB-1	WING FLAP ASYMMETRY SWITCH
671AB-2	671AB-2	REAR SPAR AND OUTBOARD AILERON
671BB	671BB	FLAP TORQUE BOX
671BB-1	671BB-1	FLAP TORQUE BOX
671CB	671CB	OUTBOARD AILERON CONTROL MODULE
671DB	671DB	OUTBOARD AILERON ACTUATOR & DAMPER
671EB	671EB	OUTBOARD AILERON DAMPER

MI-0106-06-010

R Exterior Access Doors and Panels, Zones 500 and 600
R Wing Bottom Surface
R Figure 18 (Sheet 2)

EFFECTIVITY: ALL

001B



LEFT WING UPPER SURFACE SHOWN
RIGHT WING OPPOSITE



ACCESS IDENTIFICATION NUMBER	ACCESS IDENTIFICATION NUMBER	ACCESS TO
LEFT	RIGHT	
535AT	635AT	FLUX VALVE
535BT	635BT	STRUCTURE
541A	641AT	PIN REMOVAL
551AT	651AT	INBOARD AILERON SERVO
561AT	661AT	FLAP ACTUATOR GEARBOX
561AT-1	661AT-1	PIN REMOVAL
561AT-2	661AT-2	PIN REMOVAL
561AT-3	661AT-3	PIN REMOVAL
551AT-4	661AT-4	PIN REMOVAL
561AT-5	661AT-5	PIN REMOVAL
561BT	661BT	FLAP ACTUATOR GEARBOX
561CT	661CT	FLAP ACTUATOR GEARBOX
571AT	671AT	OUTBOARD AILERON SERVO
571BT	671BT	PIN REMOVAL
571CT	671CT	PIN REMOVAL

ACCESS IDENTIFICATION NUMBER	ACCESS IDENTIFICATION NUMBER	ACCESS TO
LEFT	RIGHT	
511AT	611AT	ANGLE GEARBOX, SLAT CONTROL
511AT-1		ANGLE GEARBOX, SLAT CONTROL
511BT		POWER DRIVE UNIT
	611BY	ANGLE GEARBOX, SLAT CONTROL
511BT-1		SLAT PDU AND SHOCK ABSORBER
511CT	611CT	SLAT TORQUE LIMITING BRAKE
511DT	611DT	NO. 1 SLAT ACTUATOR
511ET	611ET	NO. 2 SLAT ACTUATOR
511FT	611FT	NO. 3 SLAT ACTUATOR
511GT	611GT	DUCTING, SLAT TORQUE TUBE
511HT	611HT	DUCTING, SLAT TORQUE TUBE
511JT	611JT	DUCTING, SLAT TORQUE TUBE
511KT	611KT	DUCTING, SLAT TORQUE TUBE
511LT	611LT	DUCTING, SLAT TORQUE TUBE
511MT	611MT	DUCTING, SLAT TORQUE TUBE
511NT	611NT	WING ANTI-ICE REGULATING/SHUTOFF VALVE, ENG ISOLATION VALVE AND BLEED DUCT OVERPRESSURE RELIEF VALVE
511PT	611PT	DUCTING, SLAT TORQUE TUBE
511QT	611QT	DUCTING, SLAT TORQUE TUBE
511RT	611RT	DUCTING, SLAT TORQUE TUBE
521AT	621AT	DUCTING, SLAT TORQUE TUBE
521BT	621BT	DUCTING, SLAT TORQUE TUBE
521CT	621CT	DUCTING, SLAT TORQUE TUBE
521DT	621DT	SLAT ACTUATOR
521DT-1	621DT-1	SLAT ACTUATOR
521DT-2	621DT-2	SLAT ACTUATOR
521ET	621ET	DUCTING, SLAT TORQUE TUBE
521FT	621FT	DUCTING, SLAT TORQUE TUBE
521GT	621GT	DUCTING, SLAT TORQUE TUBE
521HT	621HT	SLAT ACTUATOR
521HT-1	621HT-1	SLAT ACTUATOR
521HT-2	621HT-2	SLAT ACTUATOR
521JT	621JT	DUCTING, SLAT TORQUE TUBE
521KT	621KT	DUCTING, SLAT TORQUE TUBE
521LT	621LT	DUCTING, SLAT TORQUE TUBE
521MT	621MT	SLAT ACTUATOR
521MT-1	621MT-1	SLAT ACTUATOR
521MT-2	621MT-2	SLAT ACTUATOR
521NT	621NT	DUCTING, SLAT TORQUE TUBE
521PT	621PT	DUCTING, SLAT TORQUE TUBE
521QT	621QT	DUCTING, SLAT TORQUE TUBE
521RT	621RT	SLAT ACTUATOR
521RT-1	621RT-1	SLAT ACTUATOR
521RT-2	621RT-2	SLAT ACTUATOR
521ST	621ST	DUCTING, SLAT TORQUE TUBE
521TT	621TT	DUCTING, SLAT TORQUE TUBE
531AT	631AT	TANK 1/3 FUEL LEVEL CONTROL AND VENT FLOAT VALVE
532AT	632AT	TANK 2L/2R FUEL LEVEL CONTROL AND VENT FLOAT VALVE
534AT	634AT	VENT BOX INTERIOR

551-0104-06-043

Exterior Access Doors and Panels, Zones 500 and 600
Wing Upper Surface
Figure 19

EFFECTIVITY: ALL

0018



NO. 1 INBOARD SLAT



NO. 2 INBOARD SLAT



NO. 3 INBOARD SLAT

(LEFT SHOWN, RIGHT OPPOSITE)



ZONES 512, 613, 614

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
512/612AB	PANEL, STRUCT. WBL 136 TO ISHS 31
512/612BB	PANEL, STRUCT. ISHS 31 TO ISHS 56
512/612CB	PANEL, STRUCT. ISHS 56 TO ISHS 82
512/612DB	PANEL, STRUCT. ISHS 82 TO ISHS 108
513/613AB	PANEL, STRUCT. ISHS 108 TO ISHS 135
513/613BB	PANEL, STRUCT. ISHS 135 TO ISHS 162
513/613CB	PANEL, STRUCT. ISHS 162 TO ISHS 189
513/613DB	PANEL, STRUCT. ISHS 189 TO ISHS 216
514/614AB	PANEL, STRUCT. ISHS 216 TO ISHS 244
514/614BB	PANEL, STRUCT. ISHS 244 TO ISHS 272
514/614CB	PANEL, STRUCT. ISHS 272 TO ISHS 300
514/614DB	PANEL, STRUCT. ISHS 300 TO ISHS 322

M1-0100-06-135

Exterior Access Doors and Panels, Zones 512-514, 612-614
Inboard Slats
Figure 20

R

EFFECTIVITY: ALL

001B





ZONES 522, 523, 524, 525

ACCESS IDENTIFICATION NUMBER	ACCESS IDENTIFICATION NUMBER	DESCRIPTION/USE
LEFT	RIGHT	
522AL	622AR	PANEL, SLAT STRUCTURE
522BL	622BR	PANEL, SLAT STRUCTURE
522CL	622CR	PANEL, SLAT STRUCTURE
522DL	622DR	PANEL, SLAT STRUCTURE
522EL	622ER	PANEL, SLAT STRUCTURE
522FL	622FR	PANEL, SLAT STRUCTURE
522GL	622GR	PANEL, SLAT STRUCTURE
522HL	622HR	PANEL, SLAT STRUCTURE
523AL	623AR	PANEL, SLAT STRUCTURE
523BL	623BR	PANEL, SLAT STRUCTURE
523CL	623CR	PANEL, SLAT STRUCTURE
523DL	623DR	PANEL, SLAT STRUCTURE
523EL	623ER	PANEL, SLAT STRUCTURE
523FL	623FR	PANEL, SLAT STRUCTURE
523GL	623GR	PANEL, SLAT STRUCTURE
523HL	623HR	PANEL, SLAT STRUCTURE
524AL	624AR	PANEL, SLAT STRUCTURE
524BL	624BR	PANEL, SLAT STRUCTURE
524CL	624CR	PANEL, SLAT STRUCTURE
524DL	624DR	PANEL, SLAT STRUCTURE
524EL	624ER	PANEL, SLAT STRUCTURE
524FL	624FR	PANEL, SLAT STRUCTURE
524GL	624GR	PANEL, SLAT STRUCTURE
524HL	624HR	PANEL, SLAT STRUCTURE
525AL	625AR	PANEL, SLAT STRUCTURE
525BL	625BR	PANEL, SLAT STRUCTURE
525CL	625CR	PANEL, SLAT STRUCTURE
525DL	625DR	PANEL, SLAT STRUCTURE
525EL	625ER	PANEL, SLAT STRUCTURE
525FL	625FR	PANEL, SLAT STRUCTURE
525GL	625GR	PANEL, SLAT STRUCTURE
525HL	625HR	PANEL, SLAT STRUCTURE
525JL	625JR	PANEL, SLAT STRUCTURE
525KL	625KR	PANEL, SLAT STRUCTURE

R Exterior Access Doors and Panels, Zones 522-525, 622-625
R Outboard Slats
R Figure 21

EFFECTIVITY: ALL

001e



ACCESS IDENTIFYING NUMBER	ACCESS TO
712A	NOSE LANDING GEAR, FWD, RIGHT
713A	NOSE LANDING GEAR, FWD, LEFT
714A	NOSE LANDING GEAR, AFT, RIGHT
715A	NOSE LANDING GEAR, AFT, LEFT
732A	MAIN LANDING GEAR, INBOARD, LEFT
733A	MAIN LANDING GEAR, OUTBOARD, LEFT
744A	MAIN LANDING GEAR, STRUT, LEFT
742A	MAIN LANDING GEAR, INBOARD, RIGHT
743A	MAIN LANDING GEAR, OUTBOARD, RIGHT
744A	MAIN LANDING GEAR, STRUT, RIGHT



M1-0101-06-009

Exterior Access Doors and Panels, Zone 700
Nose and Main Landing Gear Doors
Figure 22



LEFT SIDE VIEW



RIGHT SIDE VIEW

DOOR IDENTIFICATION	ACCESS TO	DOOR IDENTIFICATION	ACCESS TO
821	FORWARD CARGO COMPARTMENT	842	FORWARD PASSENGER COMPARTMENT
822	GALLEY	843	MID PASSENGER COMPARTMENT
823	CENTER CARGO COMPARTMENT	844	AFT PASSENGER COMPARTMENT
824	AFT CARGO COMPARTMENT	845	AFT PASSENGER COMPARTMENT
831	FLIGHT STATION		
832	FORWARD PASSENGER COMPARTMENT		
833	MID PASSENGER COMPARTMENT		
834	AFT PASSENGER COMPARTMENT		
835	AFT PASSENGER COMPARTMENT		

M1-0002-06-009

Exterior Access Doors and Panels, Zone 800
Doors, Left and Right Side
Figure 23

R

EFFECTIVITY: ALL

0018

INTERIOR ACCESS DOORS and REMOVABLE PANELS
DESCRIPTION and OPERATION

1. General

Internal maintenance access doors, service doors, fillets, fairings, removable floor panels, removable cargo compartment panels and ceiling panels are identified by the three-digit zone number and two letter suffix as described in 6-40-00.

Location identification and function of internal access doors and removable panels are shown as follows:



PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
111BZ	ACCESS, FLIGHT STATION FROM NADOME AREA - LEFT
111CZ	ACCESS, FLIGHT STATION FROM RADOME AREA - RIGHT

Rev 7947
M1-0101-06-001

R
R

Interior Panels, Zone 111, Nose Radome
Figure 1



PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
113CZ	ACCESS, HEAT EXCHANGER HEADER CHECK VALVE
113DZ	ACCESS, HEAT EXCHANGER HEADER CHECK VALVE
113EZ	ACCESS, HEAT EXCHANGER HEADER CHECK VALVE

MI-010-06-098

Interior Panels, Zone 113, Forward Fuselage
Figure 2



(A)
LEFT SIDEWALL PANELS



(B)
RIGHT SIDEWALL PANELS



(A)



FORWARD BULKHEAD
(LOOKING FORWARD)



AFT BULKHEAD
(LOOKING AFT)

(C)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
121AL	FWD BULKHEAD, FS 449
121BL	FWD BULKHEAD, FS 449
121BR	FWD BULKHEAD, FS 449
121CL	BLOWOUT PANEL, AFT BULKHEAD, FS 703
121CR	BLOWOUT PANEL, AFT BULKHEAD, FS 703
121DL	BLOWOUT PANEL, AFT BULKHEAD, FS 703
121DR	BLOWOUT PANEL, AFT BULKHEAD, FS 703
122GR	SLOPING SIDEWALL, STRUCT, FS 451 TO FS 549
122ER	VERT SIDEWALL, STRUCT, FS 451 TO FS 549
122ER-1	BLOWOUT PANEL
122ER-2	BLOWOUT PANEL
122ER-3	BLOWOUT PANEL
122FR	SLOPING SIDEWALL, STRUCT, FS 549 TO FS 629
122GR	ACCESS, LOADER CONTROL WIRING
122HR	VERTICAL SIDEWALL, STRUCT, FS 549 TO FS 589
122HR-1	BLOWOUT PANEL
122HR-2	ACCESS, PRESSURIZATION SAFETY VALVE AND STATIC DRAIN
122JR	VERTICAL SIDEWALL, STRUCT, FS 589 TO FS 629
122JR-1	BLOWOUT PANEL, ACCESS ECS DUCT FAN, DOOR GEARBOX AND CARGO COMPARTMENT OVERTEMPERATURE SWITCH
122JR-2	BLOWOUT PANEL
123EL	SLOPING SIDEWALL, STRUCT, FS 449 TO FS 529
123FL	VERTICAL SIDEWALL, STRUCT, FS 449 TO FS 509
123FL-1	BLOWOUT PANEL
123FL-2	BLOWOUT PANEL, ACCESS TO ECS, DUCTING AND HYDRAULIC LINES
123GL	SLOPING SIDEWALL, STRUCT, FS 529 TO FS 609
123HL	VERTICAL SIDEWALL, STRUCT, FS 549 TO FS 609
123HL-1	BLOWOUT PANEL
123HL-2	BLOWOUT PANEL
123JL	SLOPING SIDEWALL, STRUCT, FS 609 TO FS 703
123KL	VERTICAL SIDEWALL, STRUCT, FS 609 TO FS 703
123KL-1	BLOWOUT PANEL
123KL-2	BLOWOUT PANEL, ACCESS TO ECS DUCTING AND HYDRAULIC LINES
123KL-3	BLOWOUT PANEL
123KL-4	ACCESS, ECS VALVE
123LL	VERTICAL SIDEWALL, STRUCT, FS 509 TO FS 549
123LL-1	ACCESS, ECS DUCTING AND HYDRAULIC LINES
123LL-2	BLOWOUT PANEL

M1-4004-06-095

R Interior Panels, Zone 122-123, Forward Cargo Compartment
R Figure 3

EFFECTIVITY: ALL

0018



ZONE 124



FORWARD CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING DOWN)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
124AT	FLOOR PANEL, STRUCT, FS 449 TO FS 489
124BT	FLOOR PANEL, STRUCT, FS 449 TO FS 489
124CT	ACCESS, EXTERNAL ELECT, PWR, RECEPTACLE
124DT	FLOOR PANEL, STRUCT, FS 489 TO FS 529
124ET	FLOOR PANEL, STRUCT, FS 489 TO FS 529
124FT	FLOOR PANEL, STRUCT, FS 529 TO FS 569
124GT	FLOOR PANEL, STRUCT, FS 529 TO FS 569
124HT	FLOOR PANEL, STRUCT, FS 569 TO FS 609
124JT	FLOOR PANEL, STRUCT, FS 569 TO FS 609
124KT	FLOOR PANEL, STRUCT, FS 609 TO FS 649

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
124LT	ACCESS, FWD OUTFLOW VALVE
124MT	FLOOR PANEL, STRUCT, FS 609 TO FS 649
124NT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124PT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124QT	FLOOR PANEL, STRUCT, FS 689 TO FS 709
124RT	ACCESS, FLOOR DRAIN
124ST	ACCESS, SUMP DRAIN TANK VALVE
124TT	FLOOR PANEL, STRUCT, FS 689 TO FS 709
124UT	ACCESS, FLOOR DRAIN MANIFOLD
124VT	ACCESS, FLOOR DRAIN MANIFOLD

HH 7722
M1-0102-06-052

Interior Panels, Zone 124, Forward Cargo Compartment Floor
Figure 4





FORWARD CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING DOWN)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE	PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
124AT	FLOOR PANEL, STRUCT, FS 449 TO FS 489	124LT	ACCESS, FWD OUTFLOW VALVE
124BT	FLOOR PANEL, STRUCT, FS 449 TO FS 489	124MT	FLOOR PANEL, STRUCT, FS 609 TO FS 649
124CT	ACCESS, EXTERNAL ELECT. PWR. RECEPTACLE	124NT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124DT	FLOOR PANEL, STRUCT, FS 489 TO FS 529	124PT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124ET	FLOOR PANEL, STRUCT, FS 489 TO FS 529	124QT	FLOOR PANEL, STRUCT, FS 689 TO FS 703
124FT	FLOOR PANEL, STRUCT, FS 529 TO FS 569	124RT	ACCESS, FLOOR DRAIN
124GT	FLOOR PANEL, STRUCT, FS 529 TO FS 569	124ST	ACCESS, SUMP DRAIN TANK VALVE
124HT	FLOOR PANEL, STRUCT, FS 569 TO FS 609	124TT	FLOOR PANEL, STRUCT, FS 689 TO FS 703
124HT-1	ACCESS, HEAT EXCH THERMAL SW.	124UT	ACCESS, FLOOR DRAIN MANIFOLD
124JT	FLOOR PANEL, STRUCT, FS 569 TO FS 609	124VT	ACCESS, FLOOR DRAIN MANIFOLD
124KT	FLOOR PANEL, STRUCT, FS 609 TO FS 649		

HH 7722
M1-5500-06-179

Interior Panels, Zone 124, Forward Cargo Compartment Floor
Figure 4

R EFFECTIVITY: 001-031 WITH SB53-062,
R SB53-100 032 WITHOUT SB53-100
0018



FORWARD CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING DOWN)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE	PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
124AT	FLOOR PANEL, STRUCT, FS 449 TO FS 489	124MT-1	ACCESS, ALIGNMENT FITTING
124BT	FLOOR PANEL, STRUCT, FS 449 TO FS 489	124MT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124CT	ACCESS, EXTERNAL ELECT, PWR RECEPTACLE	124PT	FLOOR PANEL, STRUCT, FS 649 TO FS 689
124DT	FLOOR PANEL, STRUCT, FS 489 TO FS 529	124PT-1	ACCESS, THRESHOLD GUIDE/RESTRAINT AND ALIGNMENT FITTINGS
124ET	FLOOR PANEL, STRUCT, FS 489 TO FS 529	124PT-2	
124FT	FLOOR PANEL, STRUCT, FS 529 TO FS 569	124PT-3	
124GT	FLOOR PANEL, STRUCT, FS 529 TO FS 569	124QT	FLOOR PANEL, STRUCT, FS 689 TO FS 709
124HT	FLOOR PANEL, STRUCT, FS 569 TO FS 609	124RT	ACCESS, FLOOR DRAIN
124HT-1	ACCESS, HEAT EXCH THERMAL SW.	124ST	ACCESS, SUMP DRAIN TANK VALVE
124JT	FLOOR PANEL, STRUCT, FS 569 TO FS 609	124TT	FLOOR PANEL, STRUCT, FS 689 TO FS 709
124KT	FLOOR PANEL, STRUCT, FS 609 TO FS 649	124TT-1	ACCESS, THRESHOLD GUIDE/RESTRAINT
124LT	ACCESS, FWD OUTFLOW VALVE	124UT	ACCESS, FLOOR DRAIN MANIFOLD
124MT	FLOOR PANEL, STRUCT, FS 609 TO FS 649	124VT	ACCESS, FLOOR DRAIN MANIFOLD

M1-0000-06-216

Interior Panels, Zone 124, Forward Cargo Compartment Floor
Figure 4



PANEL IDENTIFICATION NUMBER	DESCRIPTION USE
125AB	CEILING PANEL, STRUCT. FS 449 TO FS 469
125AL	ACCESS, FLIGHT CONTROL CABLE FAIRLEADS
125BB	CEILING PANEL, STRUCT. FS 469 TO FS 509
125BL	ACCESS, FLIGHT CONTROL CABLE FAIRLEADS
125BR	ACCESS, FLIGHT CONTROL CABLE FAIRLEADS
125CB	CEILING PANEL, STRUCT. FS 509 TO FS 549
125CR	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
125DB	CEILING PANEL, STRUCT. FS 549 TO FS 589
125DL	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES
125DR	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES
125FB	CEILING PANEL, STRUCT. FS 589 TO FS 629
125FL	ACCESS, FLIGHT CONTROL CABLE FAIRLEADS AND TURNBUCKLES
125FR	ACCESS, FLIGHT CONTROL CABLE FAIRLEADS
125GB	CEILING PANEL, STRUCT. FS629 TO FS 669
125GL	ACCESS, POWER BRAKE CONTROL CABLES
125GR	ACCESS, POWER BRAKE CONTROL CABLES AND FAIRLEADS
125HB	CEILING PANEL, STRUCT. FS 669 TO FS 703
125HR	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
125HB	CEILING PANEL, STRUCT. FS 669 TO FS 703
125HL	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES
125HR	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES
125JL	ACCESS, POWER BRAKE CONTROL CABLES AND FAIRLEADS
125JR	ACCESS, POWER BRAKE CONTROL CABLES AND FAIRLEADS
125KB	ACCESS, FLIGHT CONTROL CABLES AND TURNBUCKLES
125LL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
125LR	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
125ML	ACCESS, POWER BRAKE CONTROL CABLES AND FAIRLEADS
125MR	ACCESS, POWER BRAKE CONTROL CABLES AND FAIRLEADS
125NL	ACCESS, PITCH CABLE BREAK DETECTOR
125NR	ACCESS, PITCH CABLE BREAK DETECTOR
125PL	ACCESS, SPEED BRAKE QUADRANT

M1-18105-00-053

Interior Panels, Zone 125, Forward Cargo Compartment Ceiling
Figure 5





GALLEY VIEW LOOKING AFT



RIGHT SIDE



LIFT CAGES, INTERIOR VIEW



LEFT SIDE



PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
130R	ACCESS, GALLEY LIFT CHAIN
130L	ACCESS, GALLEY LIFT CHAIN
[illegible]	ACCESS, AFT SIDE OF COLD STORAGE UNIT
132CR	ACCESS, GALLEY DOOR LINKAGE
132DR	ACCESS, AFT SIDE OF CABINETS
132ER	ACCESS, GALLEY DOOR LINKAGE
132FR	ACCESS, GALLEY TO MID-ELECT.SVC CENTER

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
133AL	ACCESS, POTABLE WATER TANK
133BL	ACCESS, POTABLE WATER TANK
133CL	ACCESS, POTABLE WATER TANK
133DL	ACCESS, DUCT FIRE EXTINGUISHER
133EL	ACCESS, WATER SHUTOFF VALVES
133FL	ACCESS, DUCT FIRE EXTINGUISHER

M1-0105-05-054

Interior Panels, Zones 132-133, Galley
Figure 6



PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
135AB	CEILING PANEL, STRUCTURE, FS 704 TO FS 749
135AL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135AR	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135BB	CEILING PANEL, STRUCTURE, FS 749 TO FS 789
135BL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135BR	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135CB	CEILING PANEL, STRUCTURE, FS 789 TO FS 829
135CL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135DB	ACCESS, GYRO
135DL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135EB	CEILING PANEL, STRUCTURE, FS 789 TO FS 829
135EL	ACCESS, FLIGHT CONTROL CABLES AND FAIRLEADS
135FB	CEILING PANEL, STRUCTURE, FS 829 TO FS 865
135FL	ACCESS, SPEED-BRAKE INPUT CABLES
135GB	CEILING PANEL, STRUCTURE, FS 865 TO FS 901
135GL	ACCESS, SMOKE DETECTOR
135HB	CEILING PANEL, STRUCTURE, FS 880 TO FS 901
135HL	ACCESS, BATT. COOLING VALVE & CONT. SENSOR
135JB	CEILING PANEL, STRUCTURE, FS 885 TO FS 943
135JL	ACCESS, BATT. COOLING VALVE & CONT. SENSOR
135KB	CEILING PANEL, STRUCTURE, FS 901 TO FS 943

M1-41600-06-209

Interior Panels, Zone 135, Galley Ceiling
Figure 7



ZONE 136



GALLEY FLOOR PANELS
VIEW LOOKING DOWN

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
136AT	FLOOR PANEL STRUCT. FS 703 TO FS 806
136BT	FLOOR PANEL STRUCT. FS 703 TO FS 806
136CT	FLOOR PANEL STRUCT. FS 806 TO FS 900
136DT	FLOOR PANEL STRUCT. FS 806 TO FS 900
136ET	ACCESS, POTABLE WATER TANK FILLER
136FT	FLOOR PANEL STRUCT. FS 900 TO FS 943
136GT	FLOOR PANEL STRUCT. FS 900 TO FS 943

MI-0102-06-056

Interior Panels, Zone 136, Galley Floor
Figure 8



ZONE 137



A

MID ELECTRICAL SERVICE CENTER FLOOR PANELS
VIEW LOOKING DOWN
(ROTATED 90°)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
137AB	ACCESS, BATTERY AREA
137BB	ACCESS, ECS FLOW CONTROL VALVE, PACK NO. 2
137CB	ACCESS ECS FLOW CONTROL VALVE, PACK NO. 3
137DB	ACCESS, BATTERY AREA
137EB	ACCESS, STRUCT. FS 943 TO FS 963
137FB	ACCESS, ECS FLOW CONTROL VALVE NO. 1
137GB	ACCESS, STRUCT. FS 943 TO FS 983
137HB	FLOOR PANEL, ECS DUCTING AND STRUCTURE
137JB	FLOOR PANEL, ECS DUCTING AND STRUCTURE
137KB	ACCESS, STRUCTURE FS963 TO FS 983

M1-2302-06-097

Interior Panels, Zone 137, Mid Electrical Service Center
Figure 9



WING CENTER SECTION BOX

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
141AZ (2) 147AZ	ACCESS HOLE TO FWD(DRY) BAY FROM KEELSON AREA ACCESS WING CENTER SECTION BOX FROM HYDRAULIC SERVICE CENTER

MI-0002-06-060

Interior Panels, Zones 141-147, Wing Center Section Box
Figure 10



ZONE 141



WING CENTER SECTION BOX

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
141AZ	ACCESS HOLE TO FWD (DRY) BAY FROM KEELSON AREA
141.3AZ	ACCESS, TANK 1A THROUGH FORWARD BULKHEAD
141.3BZ	ACCESS, TANK 1A FUEL LEVEL CONTROL SWITCH
141.4AZ	ACCESS, TANK 3A THROUGH FORWARD BULKHEAD
141.4BZ	ACCESS, TANK 3A FUEL LEVEL CONTROL SWITCH
141.7AZ	ACCESS, TANK 1A THROUGH AFT BULKHEAD
141.8AZ	ACCESS, TANK 3A THROUGH AFT BULKHEAD
147AZ	ACCESS, WING CENTER SECTION BOX FROM HYDRAULIC SERVICE CENTER

M1-0001-06-183

Interior Panels, Zones 141-147, Wing Center Section Box
Figure 10



LEFT SIDEWALL PANELS



RIGHT SIDEWALL PANELS





FORWARD BULKHEAD
(LOOKING FORWARD)



AFT BULKHEAD
(LOOKING AFT)

ZONE 150

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
151AL	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151BL	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151CR	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151DL	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151DR	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151EL	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151ER	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
152AR	ACCESS, CARGO LOADER CONTROLS
152BR	SLOPING SIDEWALL, STRUCT, FS 1371 TO FS 1463
152CR	VERTICAL SIDEWALL, STRUCT, FS 1371 TO FS 1463
152CR-1	BLOWOUT PANEL
152CR-2	BLOWOUT PANEL
152CR-3	BLOWOUT PANEL
152DR	SLOPING SIDEWALL, STRUCT, FS 1463 TO FS 1551
152ER	VERTICAL SIDEWALL, STRUCT, FS 1463 TO FS 1551
152ER-1	BLOWOUT PANEL
152ER-2	BLOWOUT PANEL
152ER-3	BLOWOUT PANEL
152FR	BLOWOUT PANEL
153CL	SLOPING SIDEWALL, STRUCT, FS 1371 TO FS 1463
153DL	VERTICAL SIDEWALL, STRUCT, FS 1371 TO FS 1463
153DL-1	ACCESS, STRUCTURE
153DL-2	BLOWOUT PANEL
153DL-3	BLOWOUT PANEL
153EL	SLOPING SIDEWALL, STRUCT, FS 1463 TO FS 1545
153FL	VERTICAL SIDEWALL, STRUCT, FS 1463 TO FS 1545
153FL-1	BLOWOUT PANEL, ACCESS CARGO HEAT EXCHANGER THERMAL SWITCH
153FL-2	BLOWOUT PANEL
153FL-3	BLOWOUT PANEL
153GL	SLOPING SIDEWALL, STRUCT, FS 1545 TO FS 1625
153HL	VERTICAL SIDEWALL, STRUCT, FS 1545 TO FS 1625
153HL-1	BLOWOUT PANEL
153HL-2	BLOWOUT PANEL

M1-0000-06-610

R Interior Panels, Zones 151-153, Center Cargo Compartment
R Figure 11

R EFFECTIVITY: 007-999
R
001B



LEFT SIDEWALL PANELS



RIGHT SIDEWALL PANELS





FORWARD BULKHEAD
(LOOKING FORWARD)



AFT BULKHEAD
(LOOKING AFT)

ZONE 150

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
151AL	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151BL	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151CR	FWD BULKHEAD, CENTER CARGO COMPARTMENT
151DL	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151DR	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151EL	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
151ER	BLOWOUT PANEL, AFT BULKHEAD, FS 1625
152AR	ACCESS, CARGO LOADER CONTROLS
152BR	SLOPING SIDEWALL, STRUCT, FS 1371 TO FS 1463
152CR	VERTICAL SIDEWALL, STRUCT, FS 1371 TO FS 1463
152CR-1	BLOWOUT PANEL
152CR-2	BLOWOUT PANEL
152CR-3	BLOWOUT PANEL
152DR	SLOPING SIDEWALL, STRUCT, FS 1463 TO FS 1551
152ER	VERTICAL SIDEWALL, STRUCT, FS 1463 TO FS 1551
152ER-1	BLOWOUT PANEL
152ER-2	BLOWOUT PANEL
152ER-3	BLOWOUT PANEL
152FR	BLOWOUT PANEL
153CL	SLOPING SIDEWALL, STRUCT, FS 1371 TO FS 1463
153DL	VERTICAL SIDEWALL, STRUCT, FS 1371 TO FS 1463
153DL-2	BLOWOUT PANEL
153DL-3	BLOWOUT PANEL
153EL	SLOPING SIDEWALL, STRUCT, FS 1463 TO FS 1545
153FL	VERTICAL SIDEWALL, STRUCT, FS 1463 TO FS 1545
153FL-1	BLOWOUT PANEL, ACCESS CARGO HEAT EXCHANGER THERMAL SWITCH
153FL-2	BLOWOUT PANEL
153FL-3	BLOWOUT PANEL
153GL	SLOPING SIDEWALL, STRUCT, FS 1545 TO FS 1625
153HL	VERTICAL SIDEWALL, STRUCT, FS 1545 TO FS 1625
153HL-1	BLOWOUT PANEL
153HL-2	BLOWOUT PANEL

M1-0004-06-081

R Interior Panels, Zones 151-153, Center Cargo Compartment
R Figure 11

R EFFECTIVITY: 007-999
R
0018



CENTER CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING OUTBD)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
154AT	FLOOR PANEL, STRUCT. FS 1371 TO FS 138.
154BT	FLOOR PANEL, STRUCT. FS 1371 TO FS 1383
154CT	FLOOR PANEL, STRUCT. FS 1383 TO FS 1423
154DT	FLOOR PANEL, STRUCT. FS 1383 TO FS 1423
154ET	FLOOR PANEL, STRUCT. FS 1423 TO FS 1463
154FT	FLOOR PANEL, STRUCT. FS 1423 TO FS 1463
154GT	FLOOR PANEL, STRUCT. FS 1463 TO FS 1501
154HT	ACCESS, DUCT FAN
154JT	FLOOR PANEL, STRUCT. FS 1463 TO FS 1501
154KT	ACCESS, AIT OUTFLOW VALVE
154LT	FLOOR PANEL, STRUCT. FS 1501 TO FS 1523
154MT	FLOOR PANEL, STRUCT. FS 1501 TO FS 1523

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
154NT	FLOOR PANEL, STRUCT. FS 1501 TO FS 1523
154PT	FLOOR PANEL, STRUCT. FS 1523 TO FS 1545
154QT	ACCESS, FLOOR DRAIN
154RT	ACCESS, SUMP DRAIN TANK VALVE
154ST	ACCESS, FLOOR DRAIN
154UT	ACCESS, FLOOR DRAIN
154VT	FLOOR PANEL, STRUCT. FS 1523 TO FS 1545
154WT	FLOOR PANEL, STRUCT. FS 1545 TO FS 1585
154XT	FLOOR PANEL, STRUCT. FS 1545 TO FS 1585
154YT	FLOOR PANEL, STRUCT. FS 1585 TO FS 1625
154ZT	FLOOR PANEL, STRUCT. FS 1585 TO FS 1625

HH 7729 MI-0102-06-082

Interior Panels, Zone 154, Center Cargo Compartment Floor
Figure 12



CENTER CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING OUTBD)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
154AT	FLOOR PANEL, STRUCT, FS 1371 TO FS 1383
154BT	FLOOR PANEL, STRUCT, FS 1371 TO FS 1383
154CT	FLOOR PANEL, STRUCT, FS 1383 TO FS 1423
154DT	FLOOR PANEL, STRUCT, FS 1383 TO FS 1423
154ET	FLOOR PANEL, STRUCT, FS 1423 TO FS 1463
154FT	FLOOR PANEL, STRUCT, FS 1423 TO FS 1463
154GT	FLOOR PANEL, STRUCT, FS 1463 TO FS 1501
154HT	ACCESS, DUCT FAN
154JT	FLOOR PANEL, STRUCT, FS 1463 TO FS 1501
154KT	ACCESS, AFT OUTFLOW VALVE
154LT	FLOOR PANEL, STRUCT, FS 1501 TO FS 1523
154MT	FLOOR PANEL, STRUCT, FS 1501 TO FS 1523
154NT	FLOOR PANEL, STRUCT, FS 1501 TO FS 1523

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
154PT	FLOOR PANEL, STRUCT, FS 1523 TO FS 1545
154QT	ACCESS, FLOOR DRAIN
154RT	ACCESS, SUMP DRAIN TANK VALVE
154ST	ACCESS, FLOOR DRAIN
154UT	ACCESS, FLOOR DRAIN
154VT	FLOOR PANEL, STRUCT, FS 1523 TO FS 1545
154WT	FLOOR PANEL, STRUCT, FS 1545 TO FS 1585
154XT	FLOOR PANEL, STRUCT, FS 1545 TO FS 1585
154XT-1	ACCESS, THRESHOLD GUIDE/RESTRAINT AND ALIGNMENT FITTINGS
154XT-2	
154ZT-1	
154ZT-2	
154YT	FLOOR PANEL, STRUCT, FS 1585 TO FS 1625
154ZT	FLOOR PANEL, STRUCT, FS 1585 TO FS 1625

MI-0100-06-213

Interior Panels, Zone 154 Center Cargo Compartment Floor
Figure 12



CENTER CARGO COMPARTMENT CEILING PANELS
(VIEW LOOKING UP)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
155AB	CEILING PANEL, STRUCT. FS 1371 TO FS 1403
155AL	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155AR	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155BB	CEILING PANEL, STRUCT. FS 1403 TO FS 1443
155BL	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155BR	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155CB	CEILING PANEL, STRUCT. FS 1443 TO FS 1480
155CL	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155CR	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155DB	CEILING PANEL, STRUCT. FS 1480 TO FS 1523
155DL	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155DR	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155EB	CEILING PANEL, STRUCT. FS 1523 TO FS 1545
155EL	ACCESS, FLIGHT CONTROL CABLES & FAIRLEADS
155FB	CEILING PANEL, STRUCT. FS 1545 TO FS 1585
155GB	CEILING PANEL, STRUCT. FS 1545 TO FS 1585
155HB	CEILING PANEL, STRUCT. FS 1585 TO FS 1625
155JB	CEILING PANEL, STRUCT. FS 1585 TO FS 1625

M1-0103-06-063

Interior Panels, Zone 155, Center Cargo Compartment Ceiling
Figure 13

R
R
0018

EFFECTIVITY: ALL



LEFT SIDE PANELS



RIGHT SIDE PANELS



AFT BULKHEAD FS 1792
(LOOKING AFT)



ZONE 160





PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
161AL	ACCESS, AFT WASTE SYSTEM
161AR	ACCESS, AFT WASTE SYSTEM
161BL	ACCESS, AFT WASTE SYSTEM
162AR	ACCESS, RIGHT SIDE COMPARTMENT
162BR	ACCESS, AFT ELECTRONIC EQUIPMENT AREA
162BR-1	BLOWOUT PANEL
162CR	VERTICAL SIDEWALL, STRUCT. FS 1625 TO FS 1665
162CR-1	BLOWOUT PANEL
162CR-2	BLOWOUT PANEL
162DR	SLOPING SIDEWALL, STRUCT. FS 1665 TO FS 1677
162FR	VERTICAL SIDEWALL, STRUCT. FS 1725 TO FS 1792
162FR-1	ACCESS, CARGO HEAT FAN AND OVERHEAT SWITCH
162FR-2	ACCESS, CARGO HEAT COLD SWITCH AND CYCLE SWITCH
162GR	VERTICAL PANEL, STRUCT. FS 1725
163AL	VERTICAL PANEL, STRUCT. FS 1745 TO FS 1792
163AL-1	BLOWOUT PANEL
163AL-2	BLOWOUT PANEL
163BL	VERTICAL PANEL, STRUCT. FS 1665 TO FS 1745
163BL-1	BLOWOUT PANEL
163BL-2	BLOWOUT PANEL
163BL-3	BLOWOUT PANEL
163CL	VERTICAL PANEL, STRUCT. FS 1625 TO FS 1685

M1-0005-G6-064

R Interior Panels, Zone 162-164, Aft Cargo Compartment
R Figure 14

R EFFECTIVITY:
R
0018



AFT CARGO COMPARTMENT CEILING PANELS
(VIEW LOOKING UP)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
165AB	CEILING PANEL, STRUCT., FS 1625 TO FS 1665
165AL	ACCESS, CONTROL CABLES AND FAIRLEADS
165AR	ACCESS, CONTROL CABLES AND FAIRLEADS
165BB	CEILING PANEL, STRUCT., FS 1665 TO FS 1705
165BR	ACCESS, CONTROL CABLES AND FAIRLEADS
165CB	ACCESS, PASSENGER CABIN
165CL	ACCESS, CONTROL CABLES AND FAIRLEADS
165CR	ACCESS, CONTROL CABLES AND FAIRLEADS
165DB	CEILING PANEL, STRUCT., FS 1665 TO FS 1685

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
165DL	ACCESS, CONTROL CABLES AND FAIRLEADS
165DR	ACCESS, CONTROL CABLES AND FAIRLEADS
165EB	CEILING PANEL, STRUCT., FS 1665 TO FS 1705
165EL	ACCESS, CONTROL CABLES AND FAIRLEADS
165ER	ACCESS, CONTROL CABLES AND FAIRLEADS
165FB	CEILING PANEL, STRUCT., FS 1705 TO FS 1745
165FL	ACCESS, CONTROL CABLES AND FAIRLEADS
165FR	ACCESS, CONTROL CABLES AND FAIRLEADS
165GB	CEILING PANEL, STRUCT., FS 1745 TO FS 1785

HH 7730 M1-0102-06-065

Interior Panels, Zone 165, Aft Cargo Compartment Ceiling
Figure 15



AFT CARGO COMPARTMENT FLOOR PANELS
(VIEW LOOKING DOWN)

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
166AT	FLOOR PANEL, STRUCT, FS 1625 TO FS 1665
166BT	FLOOR PANEL, STRUCT, FS 1625 TO FS 1665
166CT	ACCESS, FLOOR DRAIN,
166DT	ACCESS, SUMP DRAIN TANK VALVE,
166ET	FLOOR PANEL, STRUCT, FS 1625 TO FS 1665
166FT	FLOOR PANEL, STRUCT, FS 1625 TO FS 1665
166GT	FLOOR PANEL, STRUCT, FS 1665 TO FS 1725
166HT	FLOOR PANEL, STRUCT, FS 1665 TO FS 1725
166JT	FLOOR PANEL, STRUCT, FS 1665 TO FS 1725
166KT	FLOOR PANEL, STRUCT, FS 1665 TO FS 1677
166LT	FLOOR PANEL, STRUCT, FS 1725 TO FS 1792
166MT	FLOOR PANEL, STRUCT, FS 1725 TO FS 1792
166NT	FLOOR PANEL, STRUCT, FS 1725 TO FS 1792
166PT	FLOOR PANEL, STRUCT, FS 1725 TO FS 1792

HH 7275
M1-0102-06-066

Interior Panels, Zone 166, Aft Cargo Compartment Floor
Figure 16

R
R
0018

EFFECTIVITY: ALL



ZONE 210



FLIGHT COMPARTMENT FLOOR PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
211AB	FLOOR PANEL, STRUCTURE, FS 164 TO FS 235
211BB	FLOOR PANEL, STRUCTURE, FS 172 TO FS 253
211CB	ACCESS, FORWARD ELECTRONIC SERVICE CENTER
212AB	FLOOR PANEL, STRUCTURE, FS 172 TO FS 237
212BB	FLOOR PANEL, STRUCTURE, FS 242 TO FS 253
212CB	FLOOR PANEL, STRUCTURE, FS 164 TO FS 235
212DB	FLOOR PANEL, STRUCTURE, FS 189 TO FS 204

MM-17401-00-057

Interior Panels, Zone 210, Flight Compartment Floor
Figure 17



ZONE 210



PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
211AB	FLOOR PANEL, STRUCTURE, FS 164 TO FS 235
211BB	FLOOR PANEL, STRUCTURE, FS 172 TO FS 253
211CB	ACCESS FORWARD ELECTRONIC SERVICE CENTER
211EB	ACCESS, TENSION REGULATOR
212AB	FLOOR PANEL, STRUCTURE, FS 172 TO FS 237
212BB	FLOOR PANEL, STRUCTURE, FS 242 TO FS 253
212CB	FLOOR PANEL, STRUCTURE, FS 164 TO FS 235
212DB	FLOOR PANEL, STRUCTURE, FS 189 TO FS 208

MU-2004-06-106

Interior Panels, Zone 210, Flight Compartment Floor
Figure 17



ZONE 220

IDENT	DESCRIPTION/USE
221AA	FLOOR PANEL, FWD L/H LAV FS 251 TO FS 278
221AB	FLOOR PANEL, FWD L/H LAV FS 251 TO FS 278
222AA	FLOOR PANEL, FWD R/H LAV FS 251 TO FS 278
222AB	FLOOR PANEL, FWD R/H LAV FS 251 TO FS 278
223AB	ACCESS, CABLES, DUCTING, GIRT BAR
223BB	ACCESS, CABLES AND PULLEYS
223CB	ACCESS, STRUCTURE, FS 331 TO FS 349
223DB	ACCESS, STRUCTURE, FS 369 TO FS 389
223EB	ACCESS, MULTIPLEX
223FB	ACCESS, STRUCTURE, FS 347 TO FS 389
223GB	ACCESS, CABLES AND PULLEYS
223HB	FLOOR PANEL, FS 313 TO FS 331
223JB	FLOOR PANEL, FS 313 TO FS 331
223KB	FLOOR PANEL, FS 297 TO FS 313
223LB	FLOOR PANEL, FS 297 TO FS 313
223MB	FLOOR PANEL, FS 278 TO FS 328
223NB	ACCESS, ELECTRICAL CONNECTORS
223PB	FLOOR PANEL, FS 252 TO FS 297
223QB	PANEL PLUG ASSY
223RB	PANEL PLUG ASSY
224AB	ACCESS, STRUCTURE, FS 347 TO FS 389
224BB	ACCESS, DUCTING
224CB	ACCESS, DUCTING AND CABLES
224DB	ACCESS, MULTIPLEX
224EB	ACCESS, STRUCTURE, FS 319 TO FS 389 CABLES AND DUCTING
224FB	ACCESS, STRUCTURE, FS 319 TO FS 389 DUCTING AND GIRT BAR
224GB	FLOOR PANEL, FS 313 TO FS 331
224HB	FLOOR PANEL, FS 297 TO FS 331
224JB	FLOOR PANEL, FS 313 TO FS 331
224KB	FLOOR PANEL, FS 278 TO FS 331
224LB	FLOOR PANEL, FS 280 TO FS 297
224MB	FLOOR PANEL, FS 297 TO FS 314
224NB	ACCESS, ELECTRICAL CONNECTORS
224PB	PANEL PLUG ASSY
224QB	PANEL PLUG ASSY



FORWARD PASSENGER COMPARTMENT FLOOR PANELS

HH 7728
M1-500X-06-008

Interior Panels, Zone 220, Forward Passenger Compartment Floor
Figure 18



FORWARD PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE	PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
225AB	CEILING PANEL FLIGHT DATA STORAGE COMPONENTS, ELECTRICAL COMPONENTS, WATER DRAIN, DUCT	225FB	WIRING, STRUCTURE, MODULES
		225GB	CEILING PANEL AIR CONDITIONING DUCT, DOOR TRACKS
225BB	CEILING PANEL ELECTRICAL WIRING, MODULES, DUCT	225HB	CEILING PANEL AIR CONDITIONING DUCT, DOOR TRACKS
225CB	CEILING PANEL ELECTRICAL EQUIPMENT PANEL, WIRING	226AB	CEILING PANEL DUCTS, DOOR MECHANISM WIRING
225DB	CEILING PANEL AIR CONDITIONING DUCT, STRUCTURE	226BB	CEILING PANEL DUCTS, DOOR TRACKS, WIRING, WATER DRAINS
225EB	CEILING PANEL WIRING, STRUCTURE, DOOR MECHANISM	226CB	CEILING PANEL DOOR TRACKS & MECHANISM, STRUCTURE

HH 7697
A11-5002-06-089

Interior Panels, Zone 220, Forward Passenger Compartment Ceiling
Figure 19



FORWARD PASSENGER COMPARTMENT FLOOR PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
231AB	FLOOR PANEL, FS328 TO FS449
231BB	FLOOR PANEL, FS328 TO FS449
231CB	FLOOR PANEL, FS328 TO FS449
231DB	ACCESS, CONTROL CABLES
231DB-1	ACCESS, MULTIPLEX
231EB	ACCESS, STRUCTURE FS349 TO FS449
231FB	FLOOR PANEL, FS 449 TO FS549
231GB	FLOOR PANEL, FS449 TO FS549
231HB	FLOOR PANEL, FS449 TO FS549
231JB	FLOOR PANEL, FS449 TO FS549
231KB	FLOOR PANEL, FS449 TO FS549
231LB	FLOOR PANEL, FS549 TO FS649
231MB	FLOOR PANEL, FS549 TO FS649
231NB	FLOOR PANEL, FS549 TO FS649
231PB	FLOOR PANEL, FS549 TO FS649
231QB	FLOOR PANEL, FS549 TO FS649
232AB	ACCESS, STRUCTURE FS349 TO FS389
232BB	ACCESS, STRUCTURE FS389 TO FS449
232CB	ACCESS, DUCTING, CONTROL CABLES
232DB	ACCESS, DUCTING, CONTROL CABLES, PULLEYS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
232EB	ACCESS, MULTIPLEX
232FB	FLOOR PANEL, FS449 TO FS469
232GB	FLOOR PANEL, FS449 TO FS469
232HB	FLOOR PANEL, FS449 TO FS469
232JB	FLOOR PANEL, FS449 TO FS549
232KB	FLOOR PANEL, FS449 TO FS509
232LB	FLOOR PANEL, FS469 TO FS549
232MB	FLOOR PANEL, FS389 TO FS449
232NB	FLOOR PANEL, FS389 TO FS449
232PB	FLOOR PANEL, FS389 TO FS449
232QB	FLOOR PANEL, FS449 TO FS509
232RB	FLOOR PANEL, FS449 TO FS549
232SB	FLOOR PANEL, FS449 TO FS549
232TB	FLOOR PANEL, FS449 TO FS549
232UB	FLOOR PANEL, FS549 TO FS649
232VB	FLOOR PANEL, FS549 TO FS649
232WB	FLOOR PANEL, FS549 TO FS649
232XB	FLOOR PANEL, FS549 TO FS649
232YB	FLOOR PANEL, FS549 TO FS649

HH 7692 M1-5002-06-070

Interior Panels, Zone 230, Forward/Mid Passenger Compartment Floor
Figure 20



FORWARD PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
233AB	CEILING PANEL, AIR CONDITIONING DUCTS, WATER DRAINS
233BB	CEILING PANEL, AIR CONDITIONING DUCTS
233CB	CEILING PANEL, ELECTRICAL DISCONNECT PANEL, MODULES, WATER DRAINS
233DB	CEILING PANEL, RECTIFIER, STRUCTURE, WIRING, MODULES
233EB	CEILING PANEL, MOTION PICTURE PROJECTOR
233FB	CEILING PANEL, MOTION PICTURE PROJECTOR
234AB	CEILING PANEL, ELECTRICAL DISCONNECT PANEL, WATER DRAINS
234BB	CEILING PANEL, WIRING, MODULES, STRUCTURE

HH7686
M1-0102-06-071

Interior Panels, Zone 230, Forward/Mid Passenger Compartment Ceiling
Figure 21



FORWARD PASSENGER COMPARTMENT FLOOR PANELS - ZONE 240

PANEL IDENT NO.	DESCRIPTION USE
241AB	FLOOR PANEL FS 649 TO FS 749
241BB	FLOOR PANEL FS 649 TO FS 749
241CB	FLOOR PANEL FS 649 TO FS 749
241DB	FLOOR PANEL FS 649 TO FS 749
241EB	FLOOR PANEL FS 649 TO FS 749
241FB	ACCESS, LAMP ASSEMBLY TRANSFORMER
241GB	ACCESS, MULTIPLEX
241HB	FLOOR PANEL FS 749 TO FS 846.25
241JB	FLOOR PANEL FS 749 TO FS 846.25
241KB	ACCESS, MULTIPLEX
241LB	FLOOR PANEL FS 749 TO FS 846.25
241MB	ACCESS, STRUCT., FS 846.25 - FS 901, GIRT BAR
241NB	FLOOR PANEL FS 865 TO FS 901
241PB	FLOOR PANEL FS 749 TO FS 846.25
241QB	PLUG PANEL
241RB	PLUG PANEL
241SB	ACCESS, ELECTRICAL CONNECTORS
241TB	FLOOR PANEL FS 846.25 TO FS 865
241UB	FLOOR PANEL FS 846.25 TO FS 865
241VB	FLOOR PANEL FS 846.25 TO FS 865
242AB	FLOOR PANEL FS 649 TO FS 749
242BB	FLOOR PANEL FS 649 TO FS 749
242CB	FLOOR PANEL FS 649 TO FS 749

PANEL IDENT NO.	DESCRIPTION USE
242DB	FLOOR PANEL FS 649 TO FS 749
242EB	ACCESS, CARGO DOOR ROTARY ACTUATOR
242EB-1	ACCESS, CARGO DOOR GEARBOX
242EB-2	ACCESS, CARGO DOOR ROTARY ACTUATOR
242FB	ACCESS, LAMP ASSY XFRMR, DOOR GEARBOX
242GB	FLOOR PANEL FS 749 TO FS 846.25
242GB-1	ACCESS, MULTIPLEX
242HB	FLOOR PANEL FS 749 TO FS 846.25
242JB	ACCESS, GALLEY EMERGENCY EXIT
242KB	FLOOR PANEL FS 749 TO FS 846.25
242LB	FLOOR PANEL FS 749 TO FS 846.25
242MB	ACCESS, MULTIPLEX
242NB	FLOOR PANEL FS 865 TO FS 901
242PB	FLOOR PANEL FS 865 TO FS 901
242QB	ACCESS, STRUCT., FS 846.25 - FS 901, GIRT BAR
242RB	FLOOR PANEL FS 749 TO FS 846.25
242SB	PLUG PANEL
242TB	PLUG PANEL
242UB	ACCESS, ELECTRICAL CONNECTORS
242VB	FLOOR PANEL FS 846.25 TO FS 865
242WB	FLOOR PANEL FS 846.25 TO FS 865
242XB	ACCESS, ELECTRICAL CONNECTORS

MI-5004-06-072

Interior Panels, Zone 240, Forward/Mid Passenger Compartment Floor
Figure 22



ZONE 240



FORWARD PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION/ USE
243AB	CEILING PANEL, AIR CONDITIONING DUCTS, STRUCTURE
243BB	CEILING PANEL, MOTION PICTURE PROJECTOR
243CB	CEILING PANEL, AIR CONDITIONING DUCTS, STRUCTURE
243DB	CEILING PANEL, ELECTRICAL EQUIPMENT PANELS, DUCTS
243EB	CEILING PANEL, WIRING, MODULES, WATER DRAINS
243FB	CEILING PANEL, WIRING, MODULES, STRUCTURE
243GB	CEILING PANEL, DOOR TRACKS, WIRING, MODULE
243HB	CEILING PANEL, DOOR TRACKS, DOOR MECHANISM

PANEL IDENTIFICATION NUMBER	DESCRIPTION/ USE
243JB	CEILING PANEL, ELECTRICAL EQUIPMENT PANELS, DUCTS
243KB	CEILING PANEL, MOTION PICTURE PROJECTOR
244AB	CEILING PANEL, WIRING, MODULES, WATER DRAINS, DUCTS
244BB	CEILING PANEL, WIRING, MODULES, WATER DRAINS, DUCTS
244CB	CEILING PANEL, DOOR TRACKS, WIRING, MODULES
244DB	CEILING PANEL, DOOR TRACKS, DOOR MECHANISM

1H7726

Interior Panels, Zone 240, Forward/Mid Passenger Compartment Ceiling
Figure 23



ZONE 250



CENTER PASSENGER COMPARTMENT FLOOR PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
251AB	FLOOR PANEL FS 901 TO FS 980
251BB	FLOOR PANEL FS 901 TO FS 980
251CB	FLOOR PANEL FS 901 TO FS 980
251DB	ACCESS, CONTROL CABLES
251EB	ACCESS, MULTIPLEX
251EB-1	FLOOR PANEL FS 943 TO FS 980
251FB	FLOOR PANEL FS 942 TO FS 980
251GB	ACCESS, STRUCTURE FS 980 TO FS 1103, HEATED PANEL
251HB	ACCESS, STRUCTURE FS 980 TO FS 1103, CONDUIT, HEATED PANEL
251JB	ACCESS, STRUCTURE FS 980 TO FS 1103, CONTROL CABLES, HEATED PANEL
251KB	ACCESS, STRUCTURE FS 980 TO FS 1103 CONTROL CABLES, HEATED PANEL
251LB	ACCESS, STRUCTURE FS 980 TO FS 1103, HEATED PANEL
251MB	ACCESS, STRUCTURE FS 980 TO FS 1103, HEATED PANEL
251NB	ACCESS, STRUCTURE, FS 1103 TO FS 1163, HEATED PANEL
251NB-1	ACCESS, MULTIPLEX
251PB	ACCESS, STRUCTURE, FS 1103 TO FS 1163, CONDUIT, HEATED PANEL
251PB-1	ACCESS, MULTIPLEX
251QB	ACCESS, STRUCTURE, FS 1103 TO FS 1163, CONTROL CABLES, HEATED PANEL
251RB	ACCESS, STRUCTURE FS 1103 TO FS 1223 CONTROL CABLES, HEATED PANEL
251SB	ACCESS, STRUCTURE, FS 1103 TO FS 1223, HEATED PANEL
251SB-1	ACCESS, MULTIPLEX
251TB	ACCESS, STRUCTURE, FS 1103 TO FS 1223, HEATED PANEL
251UB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, HEATED PANEL
251VB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, CONDUIT, HEATED PANEL
251WB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, CONTROL CABLES, HEATED PANEL

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
251XB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, HEATED PANEL
251YB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, CONDUIT, HEATED PANEL
251ZB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, CONTROL CABLES, HEATED PANEL
252AB	ACCESS, CONTROL CABLES
252BB	ACCESS, MULTIPLEX
252BB-1	FLOOR PANEL FS 943 TO FS 980
252CB	FLOOR PANEL FS 901 TO FS 980
252DB	FLOOR PANEL FS 901 TO FS 980
252EB	FLOOR PANEL FS 901 TO FS 980
252FB	ACCESS, STRUCTURE, FS 980 TO FS 1103, CONTROL CABLES, HEATED PANEL
252GB	ACCESS, STRUCTURE, FS 980 TO FS 1103, CONTROL CABLES, HEATED PANEL
252HB	ACCESS, STRUCTURE, FS 980 TO FS 1103, HEATED PANEL
252JB	ACCESS, STRUCTURE, FS 980 TO FS 1103, HEATED PANEL
252KB	ACCESS, STRUCTURE, FS 1103 TO FS 1223, CONTROL CABLES, HEATED PANEL
252KB-1	ACCESS, MULTIPLEX
252LB	ACCESS, STRUCTURE FS 1103 TO FS 1163, CONTROL CABLES, HEATED PANEL
252MB	ACCESS, STRUCTURE, FS 1103 TO FS 1163, HEATED PANEL
252MB-1	ACCESS, MULTIPLEX
252NB	ACCESS, STRUCTURE, FS 1103 TO FS 1163, HEATED PANEL
252PB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, CONTROL CABLES, HEATED PANEL
252QB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, HEATED PANEL
252RB	ACCESS, STRUCTURE, FS 1163 TO FS 1204, HEATED PANEL
252SB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, CONTROL CABLES, HEATED PANEL
252TB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, HEATED PANEL
252UB	ACCESS, STRUCTURE, FS 1204 TO FS 1243, HEATED PANEL

M1-1801-06-113

Interior Panels, Zone 250, Mid/Aft Passenger Compartment Floor
Figure 24



ZONE 250



AFT PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
253AB	CEILING PANEL, AIR CONDITIONING DUCTS, WIRING
253BB	CEILING PANEL, AIR CONDITIONING DUCTS, WIRING
253CB	CEILING PANEL, AIR CONDITIONING DUCTS, WIRING
253DB	CEILING PANEL, AIR CONDITIONING DUCTS, WIRING
253EB	CEILING PANEL, MOTION PICTURE PROJECTOR
253FB	CEILING PANEL, WIRING, MODULES, STRUCTURE
253GB	CEILING PANEL, WIRING, MODULES, STRUCTURE
253HB	CEILING PANEL, WIRING, MODULES, STRUCTURE
253JB	CEILING PANEL, WIRING, MODULES, STRUCTURE
253KB	CEILING PANEL, MOTION PICTURE PROJECTOR
254AB	CEILING PANEL, WIRING, MODULES, STRUCTURE
254BB	CEILING PANEL, WIRING, MODULES, STRUCTURE
254CB	CEILING PANEL, WIRING, MODULES, STRUCTURE
254DB	CEILING PANEL, WIRING, MODULES, STRUCTURE

IHI 7733
M1-0102-06-075

Interior Panels, Zone 250, Mid/Aft Passenger Compartment Ceiling
Figure 25

ZONE 260



AFT PASSENGER COMPARTMENT FLOOR PANELS

M1-5303-06-076

PANEL IDENTIFICATION NUMBER	DESCRIPTION USE
261AB	ACCESS, STRUCTURE, FS 1243 TO FS 1363
261BB	ACCESS, STRUCTURE, CONDUIT
261CB	ACCESS, STRUCTURE, CONTROL CABLES
261DB	ACCESS, STRUCTURE, CONTROL CABLES
261EB	ACCESS, STRUCTURE, CONTROL CABLES
261FB	ACCESS, STRUCTURE, FS 1223 TO FS 1363
261GB	ACCESS, AILERON TENSION REGULATOR
261HB	FLOOR PANEL, FS 1363 TO FS 1443
261JB	FLOOR PANEL, FS 1363 TO FS 1443
261KB	FLOOR PANEL, FS 1363 TO FS 1443
261LB	FLOOR PANEL, FS 1363 TO FS 1443
261MB	FLOOR PANEL, FS 1363 TO FS 1443
261NB	FLOOR PANEL, FS 1363 TO FS 1443
261PB	FLOOR PANEL, FS 1443 TO FS 1480.25
261QB	FLOOR PANEL, FS 1443 TO FS 1480.25
261RB	FLOOR PANEL, FS 1443 TO FS 1480.25
261SB	FLOOR PANEL, FS 1443 TO FS 1480.25
261TB	FLOOR PANEL, FS 1443 TO FS 1480.25
261UB	ACCESS, STRUCTURE GIRT BAR
261UB-1	FLOOR PANEL PLUG
261UB-2	FLOOR PANEL PLUG
261UB-3	ACCESS, ELECTRICAL CONNECTORS
261VB	ACCESS, MULTIPLEX
261XB	FLOOR PANEL, FS 1480.25 TO FS 1545

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
261XB	FLOOR PANEL, FS 1480.25 TO FS 1545
261YB	FLOOR PANEL, FS 1480.25 TO FS 1545
261ZB	FLOOR PANEL, FS 1480.25 TO FS 1545
262AB	ACCESS, STRUCTURE
262BB	ACCESS, STRUCTURE, CONTROL CABLES
262CB	ACCESS, AILERON TENSION REGULATOR
262DB	ACCESS, STRUCTURE, FS 1243 TO FS 1363
262EB	ACCESS, STRUCTURE, FS 1243 TO FS 1363
262FB	FLOOR PANEL, FS 1363 TO FS 1443
262GB	FLOOR PANEL, FS 1363 TO FS 1443
262HB	FLOOR PANEL, FS 1363 TO FS 1443
262JB	FLOOR PANEL, FS 1363 TO FS 1443
262KB	FLOOR PANEL, FS 1443 TO FS 1480.25
262LB	FLOOR PANEL, FS 1443 TO FS 1480.25
262MB	FLOOR PANEL, FS 1443 TO FS 1480.25
262NB	FLOOR PANEL, FS 1443 TO FS 1480.25
262PB	ACCESS, MULTIPLEX
262QB	ACCESS, ELECTRICAL CONNECTORS
262RB	ACCESS, STRUCTURE, GIRT BAR
262SB	FLOOR PANEL PLUG
262TB	FLOOR PANEL PLUG
262UB	FLOOR PANEL, FS 1480.25 TO FS 1545
262VB	FLOOR PANEL, FS 1480.25 TO FS 1545
262WB	FLOOR PANEL, FS 1480.25 TO FS 1545

Interior Panels, Zone 260, Mid/Aft Passenger Compartment Floor
Figure 26

ZONE 260



AFT PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
263AB	CEILING PANEL, DUCTING AND STRUCTURE
263BB	CEILING PANEL, DUCTING AND STRUCTURE
263CB	CEILING PANEL, DUCTING AND STRUCTURE
263EB	CEILING PANEL, ELECTRICAL CONNECTORS, DUCTING
263FB	CEILING PANEL, DUCTING AND STRUCTURE
263GB	CEILING PANEL, DUCTING AND STRUCTURE
263HB	CEILING PANEL, DUCTING, STRUCTURE, WATER DRAINS
263JB	CEILING PANEL, DOOR TRACKS, DUCTING
263KB	CEILING PANEL, DOOR MECHANISM, STRUCTURE
263LB	CEILING PANEL, WIRING, DUCTING, STRUCTURE

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
263MB	CEILING PANEL, WIRING, DUCTING, STRUCTURE
264AB	CEILING PANEL, DUCTING, WIRING, STRUCTURE
264BB	CEILING PANEL, DUCTING, WIRING, STRUCTURE
264CB	CEILING PANEL, DUCTING, WIRING, WATER DRAINS
264DB	CEILING PANEL, DOOR TRACKS, DUCTING, WIRING
264EB	CEILING PANEL, DOOR MECHANISM, STRUCTURE
264FB	CEILING PANEL, DUCTING, WIRING, STRUCTURE

M1-5003-06-091

Interior Panels, Zone 260, Mid/Aft Passenger Compartment Ceiling
Figure 27

R
R
001B EFFECTIVITY: ALL

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
271AB	ACCESS, MULTIPLEX
271AL	FLOOR PANEL, FS 1792 TO FS 1828
271BB	FLOOR PANEL, FS 1545 TO FS 1665
271BL	FLOOR PANEL, PLUG
271CB	FLOOR PANEL, FS 1545 TO FS 1625
271CL	FLOOR PANEL, PLUG
271DB	ACCESS, MULTIPLEX
271DB-1	ACCESS, MULTIPLEX
271EB	FLOOR PANEL, FS 1545 TO FS 1645
271FB	FLOOR PANEL, FS 1545 TO FS 1625
271GB	FLOOR PANEL, FS 1545 TO FS 1625
271HB	FLOOR PANEL, FS 1625 TO FS 1665
271JB	FLOOR PANEL, FS 1645 TO FS 1665
271KB	FLOOR PANEL, FS 1625 TO FS 1645
271LB	FLOOR PANEL, FS 1625 TO FS 1645
271MB	FLOOR PANEL, FS 1625 TO FS 1645
271NB	FLOOR PANEL, FS 1665 TO FS 1763.5
271PB	FLOOR PANEL, FS 1665 TO FS 1725
271QB	FLOOR PANEL, FS 1665 TO FS 1705
271RB	FLOOR PANEL, FS 1645 TO FS 1705
271SB	ACCESS, MULTIPLEX
271TB	ACCESS, STRUCTURE, FS 1763 TO FS 1800, GIRT BAR
271To-1	ACCESS, ELECTRICAL CONNECTORS
271UB	FLOOR PANEL, FS 1725 TO FS 1763.5
271VB	FLOOR PANEL, FS 1705 TO FS 1763.5
271WB	FLOOR PANEL, FS 1705 TO FS 1763.5
271XB	FLOOR PANEL, FS 1763.5 TO FS 1792
271YB	FLOOR PANEL, FS 1755 TO FS 1792
271ZB	FLOOR PANEL, FS 1763.5 TO FS 1792
272AB	ACCESS, MULTIPLEX
272AB-1	ACCESS, MULTIPLEX
272AR	FLOOR PANEL, FS 1705 TO FS 1725
272BB	FLOOR PANEL, FS 1545 TO FS 1625
272BR	FLOOR PANEL, FS 1725 TO FS 1763.5
272CB	FLOOR PANEL, FS 1545 TO FS 1665
272CR	FLOOR PANEL, FS 1725 TO FS 1763.5
272DB	ACCESS, MULTIPLEX
272DR	FLOOR PANEL, FS 1725 TO FS 1763.5

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
272EB	FLOOR PANEL, FS 1545 TO FS 1625
272ER	FLOOR PANEL, FS 1725 TO FS 1763.5
272FB	ACCESS, CARGO DOOR ROTARY ACTUATOR
272FB-1	ACCESS, CARGO DOOR GEARBOX
272FB-2	ACCESS, CARGO DOOR GEARBOX
272FB-3	ACCESS, CARGO DOOR GEARBOX
272FR	FLOOR PANEL, FS 1763.5 TO FS 1792
272GB	ACCESS, STRUCTURE, FS 1765 TO FS 1800 GIRT BAR
272GB-1	ACCESS, ELECTRICAL CONNECTORS
272GR	FLOOR PANEL, FS 1763.5 TO FS 1792
272HB	FLOOR PANEL, FS 1625 TO FS 1705
272HR	FLOOR PANEL, FS 1763.5 TO FS 1792
272JB	FLOOR PANEL, FS 1625 TO FS 1665
272JR	FLOOR PANEL, FS 1763.5 TO FS 1792
272KB	FLOOR PANEL, FS 1625 TO FS 1645
272KR	FLOOR PANEL, FS 1763.5 TO FS 1792
272LB	FLOOR PANEL, FS 1625 TO FS 1665
272LR	FLOOR PANEL, FS 1792 TO FS 1828
272MB	FLOOR PANEL, FS 1625 TO FS 1665
272MR	FLOOR PANEL, PLUG
272NB	FLOOR PANEL, FS 1625 TO FS 1665
272NR	FLOOR PANEL, PLUG
272PB	ACCESS, AFT CARGO COMPARTMENT
272QB	FLOOR PANEL, FS 1625 TO FS 1725
272RB	FLOOR PANEL, FS 1665 TO FS 1705
272SB	FLOOR PANEL, FS 1665 TO FS 1705
272TB	FLOOR PANEL, FS 1665 TO FS 1804
272UB	FLOOR PANEL, FS 1625 TO FS 1725
272VB	ACCESS, MULTIPLEX
272WB	FLOOR PANEL, FS 1665 TO FS 1725
272XB	FLOOR PANEL, FS 1705 TO FS 1763.5
272YB	FLOOR PANEL, FS 1705 TO FS 1763.5
272ZB	FLOOR PANEL, FS 1705 TO FS 1763.5



AFT PASSENGER COMPARTMENT FLOOR PANELS

NOTE

1 USED ON 001-014 ONLY

2 USED ON 015-999

C 881
111-5003-06-078

Interior Panels, Zone 270, Aft Passenger Compartment Floor
Figure 28



AFT PASSENGER COMPARTMENT CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
273AB	CEILING PANEL, DUCTING, RECTIFIER, WIRING
273BB	CEILING PANEL, STRUCTURE
273CB	CEILING PANEL, STRUCTURE, WIRING
273DB	CEILING PANEL, MOTION PICTURE PROJECTOR
273EB	CEILING PANEL, DUCTING, WATER DRAINS, WIRING
273FB	CEILING PANEL, ENCODER PANEL ELECTRICAL
273GB	CEILING PANEL, SUB MULTIPLEXER, WIRING
273HB	CEILING PANEL, DOOR TRACKS
273KB	CEILING PANEL, DOOR MECHANISM

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
273LB	CEILING PANEL, MOTION PICTURE PROJECTOR
273MB	CEILING PANEL, ENCODER PANEL, ELECTRICAL EQUIPMENT, WIRING, MODULES
274AB	CEILING PANEL, DUCTING, WIRING, WATER DRAINS
274BB	CEILING PANEL, DUCTING, WIRING, STRUCTURE
274CB	CEILING PANEL, DUCTING, WIRING
274FB	CEILING PANEL, DOOR MECHANISM
274GB	CEILING PANEL, DOOR TRACKS

HH 7741
M1-5002-06-092

Interior Panels, Zone 270, Aft Passenger Compartment Ceiling
Figure 29



AFT LAVATORY FLOOR PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
281A	FLOOR PANEL, RIGHT SIDE NO.1 AFT LAVATORY
281B	FLOOR PANEL, LEFT SIDE NO.1 AFT LAVATORY
282A	FLOOR PANEL, RIGHT SIDE NO.2 AFT LAVATORY
282B	FLOOR PANEL, LEFT SIDE NO.2 AFT LAVATORY
283A	FLOOR PANEL, RIGHT SIDE NO.3 AFT LAVATORY
283B	FLOOR PANEL, LEFT SIDE NO.3 AFT LAVATORY
284A	FLOOR PANEL, RIGHT SIDE NO.4 AFT LAVATORY
284B	FLOOR PANEL, LEFT SIDE NO.4 AFT LAVATORY
285A	FLOOR PANEL, RIGHT SIDE NO. 5 AFT LAVATORY
285B	FLOOR PANEL, LEFT SIDE NO.5 AFT LAVATORY

HA 1372
AM-0102-06-103

Interior Panels, Zone 280, Aft Lavatory Floor
Figure 30



ZONE 280



AFT LAVATORY CEILING PANELS

PANEL IDENTIFICATION NUMBER	DESCRIPTION/ USE
281AB	CEILING PANEL, STRUCTURE
282AB	CEILING PANEL, STRUCTURE
283AB	CEILING PANEL, STRUCTURE
284AB	CEILING PANEL, STRUCTURE
285AB	CEILING PANEL, STRUCTURE

HM 2730
Am1 0101-00-094

Interior Panels, Zone 280, Aft Lavatory Ceiling
Figure 31



PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
311BZ	ACCESS, INLET, ANTI-ICING RING
311CZ	ACCESS, INLET, ANTI-ICING RING
311EZ	ACCESS, INLET, ANTI-ICING RING
311FZ	ACCESS, INLET, ANTI-ICING RING
311HZ	ACCESS, INLET, ANTI-ICING TEMPERATURE SENSOR
311JZ	ACCESS, INLET, ANTI-ICING TEMPERATURE SENSOR
311LZ	ACCESS, INLET, ANTI-ICING TEMPERATURE SWITCH
311MZ	ACCESS, INLET, ANTI-ICING TEMPERATURE SWITCH

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
311PZ	ACCESS, INLET, ANTI-ICING RING
311QZ	ACCESS, INLET, ANTI-ICING RING
311SZ	ACCESS, INLET, ANTI-ICING RING T-DUCT
311TZ	ACCESS, INLET, ANTI-ICING RING T-DUCT
313GT	HF ANTENNA AND FAIRING
313HZ	ACCESS, HF ANTENNA, HORIZONTAL SHELF
313JZ	ACCESS, STRUCTURE, VERTICAL STABILIZER, FIXED LEADING EDGE
313KZ	ACCESS, HF ANTENNA COUPLER
314AZ	ACCESS, VERTICAL STABILIZER, LOWER CLOSURE RIB

M1-0103-06-082

Interior Panels, Zone 310, Afterbody and Center Engine Air Inlet
Figure 32



PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
313KT	CATWALK, STRUCTURE S-DUCT
313LT	CATWALK, STRUCTURE S-DUCT
313MT	CATWALK, STRUCTURE S-DUCT
313NT	CATWALK, STRUCTURE S-DUCT
313PT	CATWALK, STRUCTURE S-DUCT

Interior Panels, Zone 313, Dorsal Area Aft Saddle
Figure 33



PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
334AB 344AB	ACCESS, PIVOT AREA
334AT 344AT	ACCESS, PIVOT AREA
334A/ 344A/	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
334B/ 344B/	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
334C/ 344C/	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
335A/ 345A/	ACCESS, INBOARD ELEVATOR STRUCTURE
335B/ 345B/	ACCESS, INBOARD ELEVATOR STRUCTURE
335C / 345C/	ACCESS, INBOARD ELEVATOR STRUCTURE

HH 7866
M1-0102-06-083

Interior Panels, Zones 330-340, Horizontal Stabilizer
Figure 34



ZONE 330-340
HORIZONTAL STABILIZER
LEFT SHOWN, RIGHT OPPOSITE



ELEVATOR



PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
334AB/344AB	ACCESS, PIVOT AREA
334AT/344AT	ACCESS, PIVOT AREA
334AZ/344AZ	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
334BZ/344BZ	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
334CZ/344CZ	ACCESS, HORIZONTAL STABILIZER PIVOT BEARING AREA
335AZ/345AZ	ACCESS, INBOARD ELEVATOR STRUCTURE
335BZ/345BZ	ACCESS, INBOARD ELEVATOR STRUCTURE
335CZ/345CZ	ACCESS, INBOARD ELEVATOR STRUCTURE
333DZ/343DZ	ACCESS, HORIZONTAL STABILIZER STRUCTURE



HORIZONTAL STABILIZER
VIEW LOOKING UP AT AIR GATE



STABILIZER TRAILING EDGE





HORIZONTAL STABILIZER
STRUCTURE

M1-0001-06-365

R Interior Panels, Zone 330-340, Horizontal Stabilizer
R Figure 34

R EFFECTIVITY: 001-031 WITH SB55-014 AND 032-999
R
0018



ENGINES NO. 1 AND NO. 3 INLET ANTI-ICING RING



(VIEW LOOKING FWD)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
411/421C2	ACCESS, INLET ANTI-ICING DUCTING
411/421E2	ACCESS, INLET ANTI-ICING DUCTING
411/421GZ	ACCESS, INLET ANTI-ICING DUCTING
411/421JZ	ACCESS, INLET ANTI-ICING DUCTING
411/421LZ	ACCESS, INLET ANTI-ICING DUCTING
411/421NZ	ACCESS, INLET ANTI-ICING DUCTING

M1-0101-06-084

Interior Panels, Zones 411-421
Power Plant No. 1 and 3 Air Inlet
Figure 35



LEFT SIDE VIEW

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
412/422/432AL	ACCESS, COMPRESSOR SECTION, UPPER LEFT
412/422/432BL	ACCESS, COMPRESSOR SECTION, LEFT
412/422/432FL	ACCESS, COMPRESSOR SECTION, LEFT
412/422/432JL	ACCESS, COMBUSTION SECTION, LEFT
416/426/436BL	ACCESS, TURBINE SECTION, LEFT
417/427/437A	ACCESS, TURBINE SECTION, LOWER FAIRING
418/428/438AL	ACCESS IP DUCT, HP DUCT
418/428/438BL	ACCESS, INTERSERVICES FAIRING, LEFT
418/428/438CL	ACCESS, PYLON FAIRING, UPPER LEFT
418/428/438DL	ACCESS, AIR MOTOR
418/428/438EL	ACCESS, SUPPORT STRUCTURE
418/428/438BL-1	ACCESS, PRESSURE RELIEF DOOR LH

M1-0004-06-085

R
R
R

Interior Panels, Zones 410-420-430
Power Plant No. 1, 3, and 2
Figure 36 (Sheet 1)

EFFECTIVITY: ALL

0018



RIGHT SIDE VIEW

PANEL IDENTIFICATION NUMBER	DESCRIPTION/USE
412/422/432AR	ACCESS, COMPRESSOR SECTION, UPPER RIGHT
412/422/432BR	ACCESS, COMPRESSOR SECTION, RIGHT
412/422/432CR	ACCESS, COMPRESSOR FOR BOROSCOPE INSPECTION
412/422/432FR	ACCESS, COMPRESSOR SECTION, RIGHT
412/422/432GR	ACCESS, COMPRESSOR FOR BOROSCOPE INSPECTION
412/422/432JR	ACCESS, COMBUSTION SECTION, RIGHT
412/422/432KR5	ACCESS, EXTERNAL GEARBOX DRIVE
412/422/432LR5	ACCESS, PRESSURE RELIEF DOOR
416/426/436BR	ACCESS, TURBINE SECTION, RIGHT
417/427/437A	ACCESS, TURBINE SECTION LOWER FAIRING
417/427/437A5-1	ACCESS, LP TURBINE BOROSCOPE ACCESS PANEL RH ONLY
417/427/437A5-2	ACCESS, LP TURBINE BOROSCOPE ACCESS PANEL RH ONLY
418/428/438AR	ACCESS, IP DUCT, HP DUCT
418/428/438BR5	ACCESS, INTERSERVICES FAIRING, RIGHT
418/428/438DR5-1	ACCESS, PRESSURE RELIEF DOOR RH
418/428/438CR5	ACCESS, PYLON FAIRING, UPPER RIGHT
418/428/438DR5	ACCESS, AIR MOTOR
418/428/438ER	ACCESS, SUPPORT STRUCTURE

M1-0006-06-086

R Interior Panels, Zones 410-420-430
R Power Plant No. 1, 3, and 2
R Figure 36 (Sheet 2)

EFFECTIVITY: ALL

0018



ENGINE NO. 2 "S" DUCT ADAPTER



ZONE 430



ENGINE NO. 2 FIREWALL
(VIEW LOOKING FWD)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
431AZ	ACCESS, ENGINE NO. 2 FAN, SPINNER, IP COMPRESSOR
439AZ	ACCESS, TAIL SKID

M1-0102-06-087

Interior Panels, Zone 430, Power Plant No. 2
Figure 37



PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
451/461TZ	ACCESS, ENGINE ELECTRICAL CONNECTIONS

M1-0102-06-099

R Interior Panels, Zones 452-462, Engine Pylons No. 1 and No. 3
R Figure 38

EFFECTIVITY: ALL

0018



ZONE 471



RIGHT SIDE

NOTE

ACCESS TO PANEL 471AZ
IS THRU PANEL 471AR OPENING

PANEL IDENTIFICATION NUMBER	ACCESS TO
471AZ	ENGINE FORWARD MOUNT SUPPORT STRUCTURE

M1-0100-05-186

Interior Panels, Zone 471, Center Engine Support Structure
Figure 39



ZONE 530-630
LEFT WING SHOWN
(RIGHT OPPOSITE)

PANEL IDENTIFICATION NUMBER	DESCRIPTION / USE
532/632AZ	ACCESS, SURGE BOX COMPONENTS
532/632BZ	ACCESS, SURGE BOX COMPONENTS

HH 7698
MJ-0102-06-088

Interior Panels, Zones 530-630, Wing, Front Spar to Rear Spar
Figure 40